

INDOOR/OUTDOOR SWING GROOVER™

Important Safety Precautions*

Before taking a full swing, practice with half swings to be sure you are able to connect without topping the ball, hitting the tether cord, or hitting the ground.

- Always use the same precautions you would when playing golf.
- Never allow anyone to stand directly in front of or behind the ball.
- Allow children to use only under adult supervision.
- Be careful to hit only the ball. Topping the ball, chipping down on the ball or hitting the cord/ground will cause damage to your club and Swing Groover™.
- If you mis-hit and severely top the ball or hit the ground. Stop! Check your club head and shaft for damage. If any damage is evident discontinue using that club. The head could come off and injure you or a bystander.

When practicing, be sure no one is directly in front of the ball. Be careful to hit the ball only, consistent mis-hits could damage the product, yourself, or bystanders. We do not recommend this product to be used by beginners who have received no previous golf training. We assume no liability for misuse of this swing trainer product.

IF ANY PARTS ARE MISSING OR IF ASSISTANCE IS NEEDED TO ASSEMBLE YOUR PRACTICE NET OR IF YOU HAVE ANY QUESTIONS ABOUT THE SAFE USE OF YOUR NET, PLEASE CALL GOLF GIFTS & GALLERY: 1-800-552-4430.

INDOOR/OUTDOOR SWING GROOVER™

Set-Up Instructions

Please read and follow these instructions carefully before using your Swing Groover™. Failure to follow the instructions may result in damage to your product, golf club, or possibly cause injury to you or a bystander.

Assembly

Tools needed: Pocket wrench

As shown below, the Swing Groover™ is easy to assemble. Attach the balance base to the top of the rubber base. Line up the four shaft holes with the four balance base holes. Twist in 3/4" bolts, lock in the washers & nuts then tighten bolts with included pocket wrench.

Location

Find a flat area to set up your Swing Groover™. Set the base on the ground and secure firmly with included metal stakes. The area should be free of rocks or other debris, and allow enough room to swing the club freely. DO NOT FACE THE SWING GROOVER™ IN A DIRECTION WHERE THE BALL COULD INJURE SOMEONE IF IT WERE TO DETACH FROM THE CORD.

