


# Motion Sensing Deck Light

## Installation Instructions

### Battery Installation


- Remove mounting plate by sliding down and lifting out of keyholes.
- Remove battery cover by pressing up on tab and lifting out
- Insert 3 C alkaline batteries (not included).
- **Note:** Be sure batteries are orientated properly. Markings for +/- are engraved in the battery compartment.

*\*Estimated battery life of one year running in low light level setting.*




### Mounting Motion Deck Light

- Adjust time and light level if desired.
- Install mounting plate in desired location using screws.
- Install front cover by lining up keyholes and sliding unit down.
- Insure top of mounting plate slides into slot at the top of the unit for a secure fit.
- Install locking screw (included) through the bottom of the unit into the mounting surface to prevent removal.



### Product Specifications

- Motion Coverage – 30' by 160 degrees
- “Low-Glow” accent light runs dusk to dawn
- Three brightness settings when motion is detected:
  - TURBO - extra bright for security and convenience
  - HIGH - for walkways and entry areas
  - LOW - for outdoor living areas
- Requires 3 C alkaline batteries (not included)
- Time settings:
  - LONG - 5 min for living areas
  - SHORT - 30 sec for walkways



1 year limited warranty  
Patent # 6,992,591  
Additional patents pending

©2022 Xodus Innovations, LLC  
2025 Yore Avenue  
Benton Harbor, MI 49022  
All Rights Reserved.  
[www.xodusinnovations.com](http://www.xodusinnovations.com)

Made in China