

# **SHARPER IMAGE®**

## **LED LIGHT UP HEADBAND**

Item No. 206954

User Guide



Thank you for purchasing the LED Light Up Headband. Please take a moment to read this guide and store it for future reference.

## FEATURES


- 3 light modes
- Made of 90% Polyester and 10% Spandex
- Built-in rechargeable LED light
- Operates on a 3.7V 250mAh rechargeable li-polymer battery

## HOW TO USE

- Press the 'ON/OFF' switch on the LED light to cycle through the following functions: On / Normal Light / Blinking / Off.

## HOW TO CHARGE

Before initial use, fully charge the battery, this typically takes 1.5 hours. Charge the LED Light Up Headband using a USB charger [not included]. The battery contained within the head lamp may only be partially charged when unpacked.



- To remove the lamp unit, pull the head lamp rim open and push the lamp out from the headband. Then pull off the USB charger cover.
- Plug the head lamp USB charger plug into the corresponding socket of the USB wall charger [not included] or 12V USB car charger socket [not included], power bank or similar device with minimum DC5V 1000 mAh output USB socket.
- The battery indicator light will illuminate red while charging. When the battery is fully charged, the indicator light will illuminate green.

## LED LIGHT RUN TIME

- Low: Up to 6 hours
- Medium: Up to 3 hours
- High: Up to 1.5 hours
- Charge time: 100 minutes

## CARE AND MAINTENANCE

- Switch the device off and disconnect the charger from the socket before cleaning.
- Charge the battery fully at regular intervals, when the device has not been in use to ensure optimum battery life.
- Clean the product with a soft, dry cloth. Do not use any form of abrasive cleaner or solvents to clean the unit. Never dip the head lamp into liquids.
- Store the device in a clean, dry and dark place. Do not expose it to temperatures of under 5° F for long periods of time.

## DISPOSAL

Do not dispose of packaging or the product through your household waste! The product and packaging are made from recyclable materials [plastics, metals, paper].

If the product is no longer suitable for use dispose of it in an environmentally friendly manner in accordance with your local authority.

**Warning:** *Dispose of used batteries in accordance with local authority regulations.*

## WARRANTY AND CUSTOMER SERVICE

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. If you have any questions not covered in this guide, please call our Customer Service department at 1 [877] 210-3449. Customer Service agents are available Monday through Friday, 9:00 a.m. to 6:00 p.m. ET.

**SHARPER IMAGE®**

The SHARPER IMAGE® name and logo are registered trademarks.

©Sharper Image. All Rights Reserved.