

SHARPER IMAGE®

REPLACEMENT BLADE/FOIL SET FOR WORLD'S FASTEST CORDLESS FOIL SHAVER AND TRIMMER

Item No. 207142

HOW TO

CHANGING THE FOILS

With normal use, the foils should last a long time. However, if the foils become damaged, you can replace them easily at home. For best performance, it is recommended to change the blades at the same time as the foils.



FIG. 1
HOLD THE SHAVER FIRMLY WITH ONE HAND ON THE SHAVER HEAD AND ONE HAND ON THE BODY [FIG. 1].




FIG. 2
REMOVE THE SHAVER HEAD FROM THE BODY [FIG. 2].



FIG. 3
USING A SMALL BLADE OR SCREWDRIVER, CAREFULLY LIFT OUT THE FOILS FROM THE SIDE, ONE AT A TIME [FIG. 3-4].



FIG. 4

CHANGING THE BLADES



FIG. 5
USING YOUR HANDS ONLY, CAREFULLY INSERT THE NEW FOILS INTO THE SHAVER HEAD UNTIL THEY ARE PROPERLY SNAPPED IN PLACE. DO NOT USE TOOLS, AS THIS MAY DAMAGE THE FOILS [FIG. 5].




FIG. 6
WITH THE SHAVER HEAD DETACHED FROM THE BODY, GRASP ONE BLADE WITH YOUR THUMB AND INDEX FINGER. HOLD THE BODY FIRMLY WITH THE OTHER HAND [FIG. 6].




FIG. 7
ROCK THE BLADE SIDE TO SIDE, APPLYING GENTLE PRESSURE UNTIL IT LIFTS OFF THE BODY [FIG. 7]. REPEAT THIS STEP FOR THE OTHER BLADES.




FIG. 8
ATTACH THE NEW BLADES, USING FIRM BUT GENTLE PRESSURE [FIG. 8]. FINALLY, REPLACE THE SHAVER HEAD.

SHARPER IMAGE®

The SHARPER IMAGE® name and logo are registered trademarks.

©Sharper Image. All Rights Reserved.