



# EZ-FOLD 360° FOLD PUSH CART INSTRUCTIONS

## ASSEMBLE/OPEN




**Step 1.**

Remove all pieces from the box and lay the scorecard holder facing up. Remove the rubber cover from the pins and attach the rear wheels.




**Step 2.**

Pull up the main shaft and handle frame by holding the upper cradle to unlock the locking device.



**Step 3.**

Pull up the main shaft upward & backward until the bottom of the frame locks in place, forming a 90 degree angle. Push the **PIN** and insert / remove the front wheel.




**Step 4.**

Adjust the handle to your desired position and fasten the locking handle. The cart is now fully assembled.


Lubricate moving parts every 2 months.

## 360° Swivel




To unlock the swivel front wheel, pull up the handle brake. To lock, push down the handle brake; the front wheel will run straight line.

## FOLDING




**Step 1.**

Release the locking handle and kick in the adjustment lever to fold down the main shaft.



**Step 2.**

Push the handle frame and main shaft down together to lock the cart with an elastic strap.



**Step 3.**

Your cart is now folded and ready for transport or storage with carry strap.