



Assembly Instructions for Golf Cage Net

Included in Package:

2 Shock-cord poles 2 Storage bags


1 Net with target 7 Pins

1




Assemble both shock-cord poles.

2




Lay net flat on the ground. Locate the center portion of the net that has the color coded Red & Black pole sleeve ends and position it in the center as you're laying out the net.

3




Make sure the pole goes from one color coded sleeve to the other at the top of the net.

4




Continue to push the pole through sleeve until it comes out the end. At this point put the pin at the corner of the net into the end of the pole.

5




Now go to the opposite end of the pole and push the rest of the way into the sleeve with enough force to cause the pole to bow. Once you've inserted the pole all the way, insert the pin into the end of the pole.

6




Repeat steps 3-6 with the other pole.

7




Repeat step 5 on the other pole. This will open up the net to it's full size.

8



Put the pin through the loop of net as above shown to fix the net.

9



Note:

When hitting golf balls into the net, position yourself close enough so that errant shots don't miss net. Also, back far enough so as not to hit poles of net. This will vary depending on the golfer and club selection.

Caution: make sure there is no object or person in your club swing zone.