
Franklin®

Ages 6+

PRO HOOPS LED BASKETBALL

ITEM NUMBER: **54272 54272X**



Made In China Franklin Sports Inc. Stoughton, MA 02072



For replacement parts: Visit: www.franklinsports.com/54272 Email: parts@franklinsports.com Call: 1-800-225-8649



CUSTOMER SERVICE COMMITMENT

Thank you for purchasing this Franklin® product! In the event that the product you've purchased has missing or damaged parts, please contact us at:

parts@franklinsports.com

Visit our website at: www.franklinsports.com/54272

If possible, please include product part number and parts description so we can best assist you.

WE'RE HERE FOR YOU!

PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE IT WAS PURCHASED FROM.

WE ARE COMMITTED TO FULFILLING ALL REPLACEMENT PART NEEDS IMMEDIATELY.

Thank you for your continued support, and welcome to the #FranklinFamily!


For replacement parts:

Call: 1-800-225-8649

Visit: www.franklinsports.com/54272

Fmail: parts@franklinsports.com

PARTS LIST



2



ASSEMBLY INSTRUCTIONS

Scan this code for assembly video


- GENERAL NOTE -

 Find a clean place to begin the assembly of your Pro Hoops Basketball Game.

Franklin* ITEM#: 54272 54272X

- 3. Before assembling the set, remove the protective film from the front of the backboard.
- Remove all the parts from the box and verify that you have all of the listed parts as shown on the parts list page.

Made In China
Franklin Sports Inc.
Stoughton, MA 02072





Requires 3 "AAA" size batteries (not included). Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.



NOTE -


Locate the battery compartment on the back of the Main Board (#1) and insert (3) "AAA" Alkaline Batteries. (Not included)






NOTE -


Attach the Hooks (#6) to the Main Board (#1) using four M4 Metal Bolts (#3) and four M4 Metal Nuts (#4). Stick the Protective Foam (#13) to the inside faces of the hooks.






NOTE -


Attach the Rim (#7) to the Main Board (#1) using two Bolts (#5), one Metal Support (#2) and two Nuts (#9).








NOTE:





NOTE -

Inflate your Basketball (10) using the Inflation Pump with Needle (11) that's included.

To find the needle in the pump, simply open the top cap as shown, take the needle out of this compartment (Figure 1), and screw into the bottom of the pump (Figure 2).

GAME INSTRUCTIONS

HOW TO PLAY:

Once the unit is turned on, the game will light-up. The timer on the game will begin once the sensor under the rim is triggered. Once the game begins the unit will score until the time runs out (after 30 seconds). During this time there is only one player that should be shooting at a time. Once that players turn is over, they will record their score and the next player will start their turn by triggering the unit to countdown. This turn based play will continue until all players have had a turn. After the last player has gone, the player with the highest score will be the winner!

We welcome you to use your own balls on this set. Please note, the scoring sensor may not pick up darker colored balls.

YOU ARE NOW READY TO PLAY!

For replacement parts:

Call: 1-800-225-8649

Visit: www.franklinsports.com/54272

Email: parts@franklinsports.com