

Catalog

I Product Information.....09


II Product Structure..... 10

III How To Use It 11

IV Cleaning and Maintenance.....13

V Notes13

VI Trouble-Shooting.....15



SL008 Gold Pulse Facial Massager

I Product Information

1 Basic Information

Product Name : L-Face

Product Model : FLF921

Size:134mm*35mm*30mm

Net Weight: Metal head(without battery)60g

Silicone head(without battery)40g

Jade head(without battery)33g

Rated Voltage:1.5V

Rated current: $\leq 400\text{mA}$

Battery: Alkaline battery(a battery)

Standard: GB4706.1-2005 GB4706.10-2008

2 Features

Functions: Smooth wrinkles/Essence Import,

Sharp face, Facial cleanliness

Manipulation: Vibration

Massage Region: Face, neck, back and
other soft parts of the body

Special Functions: Portable, waterproof,
vibration function

Control mode: Button control

II Product Structure

1 Components illustrating

Metal head



Silicone Brush



Jade




2 Button illustrating




Power button
bottom

3 Battery installation /disassemble diagram



III How To Use It

1 Product power button



Power button
bottom



3 Operation guide

Please install the battery for the first time usage. After the battery loaded into the product, then you can start using the product by following operation instruction.

- 3.1 Press the button for the first time, the product power on and switch into the first vibration mode with obvious vibration;
- 3.2 Press the button for the second time, the product switch into the second vibration mode with mid-range vibration intensity;
- 3.3 Press the button for the third time, the product switch into the third vibration mode with maximum vibration intensity;
- 3.4 Press the button for the fourth time, the product switch into the fourth vibration mode and vibrate from weak to strong intensity;
- 3.5 Press the button for the fifth time, the product switch into the fifth vibration mode with flash vibration (twice short and once long vibration);

3.6 Press the button for the sixth time, the product switch into the sixth vibration mode with flash vibration;

3.7 Press the button for the seventh time, the product switch into the seventh vibration mode with fast and frequent flash vibration;

3.8 Press the button for the eighth time, the product power off;

3.9 When the device in the any of the above modes, long press to power off the product;

IV Cleaning and Maintenance

1 Cleaning

1.1 It is a waterproof device, you can use cleaning fluid and water to clean it.

1.2 Please use damp cloth or neutral detergent to clean the product and wipe dry afterwards.

1.3 Don't use sharp brush, sharp tool, gasoline and diesel to clean it.

2 Maintenance

2.1 When not using the product, please put it into a box and keep in a safe, dry and cool place.

2.2 Don't put it in any place with high temperature, near fire or direct sunlight, it may fade or be damaged.

2.3 Don't contact benzene, diluent or any other corrosive liquid.

2.4 Please remove and store the battery when you are not using the product.

Any battery leakage that occurs may cause product damage.

V Notes

For safety, please read carefully the following instructions before using.

1 Please use this device as the user's manual guides.

2 Don't use parts that offered by non-manufacturer.s , only for personal and non- professionals usage.

3 To avoid damage, please keep the product away from the hot object.

4 Stop using when the product damaged or for other reason, unable to work properly. Should be returned to service center for inspection and repair.

5 Do not let children use or direct contact with this product without adult supervision.

6 Those mobility or perceptual retardation , please use this product under guardianship.

7 This product does not make any medical purposes , only for personal and non- professionals usage.

8 If you have the following situation , please consult a doctor before using the product;.

a) Pacemakers and other implanted medical electronic equipment

b) Suffering from thrombosis or blood circulation disorders

c) Suffering from skin allergies or skin infections

9 Continuous prolonged use may lead to overheating and shorten product life. Stop use if it is overheating, Waiting for the product to be cool before operati

VI Trouble–Shooting

Trouble	Reasons/ Treatment
Can't start the massager	Battery low/ Please replace the battery before usage
The product automatically stop when working	Battery has run out /Please replace the battery before usage
Product buzzing when working	Normal sound emitted by the running motor, no need to deal with

Note:If the problem still exists, do not continue to use, contact service center (Contact details, see back cover). Do not disassemble and repair the product by yourself.