


PLEASE READ BEFORE OPERATING

Lamp Angel® Quick Start Instructions

Carefully remove lamp base, harp and shade from box. Remove ALL packing from lamp base, harp, shade and cord. Properly recycle/dispose of all packing materials (plastics can be a choking hazard, please keep away from children). If you are missing parts, please email us at sales@inpoweredlights.com



1) Install included light bulb in the lamp (Use a Maximum of Medium base 60 watt regular/incandescent, 13 watt CFL or 10 watt LED bulbs.).




2) Position harp above the lamp base and slide the holders upward while squeezing harp arms to fit into lamp base.



3) Slide holders down on harp to secure to lamp base.



4) Place shade over harp and guide the center opening of the shade over the top screw of the harp.



5) Secure shade to the harp by installing top glass knob (finial), **do not overtighten.**



CRITICAL STEPS

- Plug lamp into regular outlet, **please be sure the outlet is not controlled by a wall switch.**


• Turn switch on the side of the lamp base to “ON” position.

“o” = OFF

“-” = ON



- Lamp is ready to charge for emergency use. Failure to turn on switch means the emergency function will not be activated and charged. Leave this switch in the “ON” position. If power is lost, the light will automatically come on. Use this switch to control the On/Off of the emergency light . **WHEN POWER IS RESTORED BE SURE SWITCH IS IN ON POSITION SO IT WILL CONTINUE TO CHARGE.**



Allow the lamp to charge at least 24 hours before using the USB or emergency function.. The switch on top of the base controls the main light bulb and is ready to operate.


OPERATING COLOR CHANGE FUNCTION

You can change the colors of the base of the Lamp Angel to a large array of colors and change the style to Strobe, Flash, Fade and Smooth Transitions. There are two ways to change colors:




- 1) Remote Control—Included in box
- 2) LotusLanternX—Downloadable Smartphone app

- 1) For the remote control, remove the plastic tab to activate the battery. Point the remote at the base of the lamp and press the red ON button on the top right of the remote control and this will activate the lights inside of the lamp body. Then you can begin to choose different colors and different modes. You can control the brightness of the lights in the lamp body with the white buttons on the top left of the remote control.




Make sure your Smartphone's Bluetooth function is turned on. After the app has downloaded, open LotusLanternX app on your smartphone and confirm that the Lamp Angel is connected. To make sure your phone is connected to your Lamp Angel, click on the menu on the left hand side that looks like three dots and three lines. (see photo on the right) If it is connected, the Light Bulb will have a Green Dot, if not, click on the Refresh bottom to reconnect.



The Green Sliding Tab in the upper right hand corner controls the On/Off of the Lamp Angel.

Choose your color by clicking on the actual color at the bottom or use the center wheel to choose different shades of colors.



Click on Style to change the format and transition of the colors such as Fading, Transition, Strobe and Flash.

Click on Schedule to set up times for the lights to turn on or turn off.

Refer to the LotusLanternX app for additional functions.

The color changing function only operates during normal AC operation even while the top socket is on. ***Color changing will not function in emergency mode.***

Go to www.inpoweredlights.com for detailed installation and operating instructions.

We sincerely thank you for your Lamp Angel® purchase. May you never be caught in the dark again!