

Item Number: 208252

Item Name: Club Buddy Golf Club Caddy Stand



Simply slide The Club Buddy on your bag as needed. (Picture 1)

To remove a club: Place your thumb on the top of The Club Buddy shaft. Place your 4 fingers just below your thumb. Gently pull the club with your 4 fingers away from the shaft. The club will pop out from The Club Buddy. (Picture 2)

After you have selected the club you need, stick The Club Buddy into the ground. (Do not stick it in the putting green). (Picture 3)