


COSTWAY®



USER'S MANUAL

**Four In A Row
TY327037**

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com



Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

- ⦿ Please read all instructions carefully.
- ⦿ Retain instructions for future reference.
- ⦿ Separate and count all parts and hardware.
- ⦿ Read through each step carefully and follow the proper order.
- ⦿ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⦿ Always place the product on a flat, steady and stable surface.
- ⦿ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Four In A Row Instructions

Contents


2 x Legs – A

1 x Main Frame – B

1 x Bottom Bar – C

21 x Disks

21 x Disks



Assembly

This item should be assembled by an adult or under the direct supervision of an adult. Slide the legs A onto the sides of the main frame B. This is easier to do with the frame upside down. Then slide the horizontal bar C into the slot below the main frame. You are now ready to play!

Aim of the Game

The aim is to get 4 of your color disks in an uninterrupted row, column or diagonal line in the frame. When you achieve this you have won the game!

How to Play

Choose the color disks you want to play with and take turns slotting your counters in to the frame through the slots in the top. The winner is the first player to form a row of 4.

You can play individual games or have a best of 3 game.

When each game is complete, the counters can be removed by sliding the bottom bar C out of the slot at the bottom of the frame. Replace it before you start your next game.

Strategy

Think about blocking your opponent from forming a line, whilst at the same time building up as many chances as possible for you to win yourself. Think ahead – don't play each move in isolation. Think about placing your counters where they make potential winning lines for later. The killer tactic is to create a double attack: create a potential winning row of 4 which your opponent has to block but in doing so he creates another winning opportunity for you.

Storage

This game can be played indoors or outdoors but should be stored indoors in a cool dry place when not in use. It should not be played in the rain or left outside in the rain.

Please retain these instructions for future reference.

Suitable for 2 players aged 8+

Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us!
We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

**With your inspiring rating, COSTWAY will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!**

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to
all of our customers for taking time to assemble
this product and giving us valuable feedbacks.

THANK
YOU
😊