



QUICK START GUIDE

1. Connect the USB power cord to a suitable outlet and the magnetic cable to the back of the porcelain base. Make sure the plug is well attached and the battery's indicator light is orange.

NOTE: If the battery light turns off while connected to power, this indicates no charging is occurring, look for a connection that is not properly connected. When the light switches to white, the battery is fully charged. After a full charge the battery can work for 7-8 hours.

2. Wash the carafe with lukewarm water and washing up liquid.

3. Fill the carafe with drinking water until the 1.5 liter mark




4. Place the carafe in the center of the porcelain base.

NOTE: Ensure the metal side is facing down.

5. Lightly touch the ceramic button and let the water swirl for 5 minutes without the lid. Use the cap lid when storing the carafe in a refrigerator.

6. Enjoy your swirled water!

The MAYU Swirl kit consists of the following items:



MAINTENANCE AND CLEANING :

- The carafe and lid are dishwasher safe.

- In order to keep your water at the highest quality we recommend washing with lukewarm water and washing up liquid every 4 days.

- If you put other fluids other than water in the carafe (such as wine, juice, herbs, or fruit) please wash twice. This will ensure no organic substances remain in the carafe.

- If you use tap water daily in the carafe and you notice some sediment accumulating on the impeller, do the following:

1. Fill the carafe with 1.5 liters of lukewarm water and Add one teaspoon of citric acid/lemon salt to the water.
 2. Place the carafe on the base and let it swirl for 30 minutes.
 3. Wash well, whether by hand or dishwasher.
- If some sediments still remain, repeat the above steps.

- If you use chlorine-free water (not tap water) daily in the carafe and you notice some dirt accumulating on the impeller, do the following:

1. Mix one teaspoon of chlorine/bleach with one glass of water and pour into the carafe.

2. Let it stand for 4 hours/overnight.
3. Place the carafe on the base and let it swirl for 30 minutes.
4. Wash thoroughly 3 times with a strong water stream and washing up liquid.

Porcelain Base:

Manufactured in China, the base contains a small engine with a weight scale that matches the Swirl's speed with the amount of water in the carafe.


Troubleshooting Tips:

- For the perfect experience, ensure the carafe is well-positioned, centered, and standing vertically.
- If the vortex is noisy or not performing correctly, lift the carafe and re-center it on the base. This should resolve most issues.

All Mayu products are manufactured and inspected to the highest standards. If you found any flaws in the carafe or porcelain base, Please contact us at: contact@mayuwater.com



LED INDICATOR



TOUCH BUTTON



Swirl User manual

IMPORTANT SAFEGUARDS. SAVE THESE INSTRUCTIONS

WARNING: Risk of Electric Shock.
Disconnect power before servicing.

WARNING: Use only with Mayu Listed/Certified ITE
Power Supply.

WARNING: Read all safety warnings and instructions.
Failure to follow the warnings and instructions may result in
electric shock, fire and/or serious injury.

- ✦ Recharge only with the charger specified by the manufacturer.
Note that a charger that is suitable for one type of battery pack
may create a risk of fire when used with another battery pack.

- ✦ Use appliances only with specifically designated battery packs.
Use appliances only with specifically designated battery packs.
The use of any other battery packs may create a risk of injury and fire.

1

- ✦ When the battery pack is not in use, keep it away from other metal
objects, like paper clips, coins, keys, nails, screws or other small metal
objects that can make a connection from one terminal to another.
Shorting the battery terminals together may cause burns or a fire.
- ✦ Under abusive conditions, liquid may be ejected from the battery.
Avoid contact. If contact accidentally occurs, flush with water. If
liquid contacts eyes, additionally seek medical help. Liquid ejected
from the battery may cause irritation or burns.
- ✦ Do not use a battery pack or appliance that is damaged or modi-
fied. Damaged or modified batteries may exhibit unpredictable be-
havior resulting in fire, explosion or risk of injury.
- ✦ Do not expose a battery pack or appliance to fire or excessive tem-
perature. Exposure to fire or temperature above 130°C (265°F) may
cause an explosion.


- ✦ Follow all charging instructions and do not charge the battery
pack or appliance outside of the temperature range specified in the
instructions. Charging improperly or at temperatures outside of the
specified range may damage the battery and increase the risk of fire.
- ✦ Have servicing performed by a qualified repair person using only
replacement parts from Mayu. This will ensure that the safety of the
product is maintained.


- ✦ Do not modify or attempt to repair the appliance or the battery
pack except as indicated in the instructions for use and care.

- ✦ Switching power adapter parameter
operating temperature: 32~104°F (0~40°C)
INPUT: 100~240Vac, 50/60Hz
OUTPUT: 5Vdc, 1A

2

WARNING

 Porcelain base is not waterproof.
Do not place under running water.
Use only a damp cloth to clean the
porcelain base surface.
The porcelain base is fragile.
Mayu Swirl should be given the care
normally required for other similar
electrical appliances.

 The borosilicate glass carafe is fragile.
Glass can break and pieces can be
very sharp. Please handle with care.
Do not drop any hard objects into the
carafe while spinning.

Mayu Swirl is designed to aerate water.

 This appliance must only be supplied
at safe, extra-low voltage corresponding
to the marking on the appliance.

3

WARNING

This appliance can be used by children aged
8 years and older and persons with reduced
physical, sensory or mental capabilities or
lack of experience and knowledge, if they
have been given supervision or instruction
concerning use of the appliance in a safe
way and understand the hazards involved.

Children should not play with the appliance.

Cleaning and user maintenance should not
be done by children without supervision.

The battery must be removed from the
appliance before it is scrapped.

The appliance must be disconnected from
the power supply when removing the battery.

The battery is to be disposed of safely.
The battery must be removed from the
appliance before it is scrapped.

4

WARNING

Use only supplied the charging cable.
Make sure connections are in good condition.
DO NOT disassemble or modify the battery.
DO NOT use a damaged or leaking battery.
Do not use non-rechargeable batteries.
Use only a 18650 li-ion rechargeable battery
supplied by the manufacturer.

 This marking indicates that this
product should not be disposed
with other household waste
throughout the EU. To prevent
possible harm to the environment or
human health from uncontrolled waste dis-
posal, recycle it responsibly to promote the
sustainable reuse of material resources. To
return your used device, please use the
return and collection systems or contact
the retailer where the product was pur-
chased. They can take this product for envi-
ronmental safe recycling.

5

Replacing the rechargeable battery:

Disconnect from electricity.
Turn the device upside down.



Unscrew and remove
the metal bottom plate.



Take out the battery.



Battery Details: Single Standard 18650 Li-Ion Battery 2000 mAh.



Change battery. Make sure
to connect the two pins



Close and re-screw metal plate.



Turn the device upside-
down before turning on.

6



For more information, please visit
www.mayuwater.com
or contact us at:
contact@mayuwater.com

Mayu Water LLC
919 N Market St. Suite 950
Wilmington, DE Zipcode 19801