

GRILLIGHT

Light removal and battery replacement instructions

1 Depress release clip.



Pull light out of handle.



3 Unscrew light head.



Slide battery holder out of light body.



Remove batteries from battery holder and replace. To reassemble - reverse instructions.

