



TOUCHLESS MIST SANITIZER SET-UP GUIDE



VISIT OR CODE TO
WATCH SET-UP
VIDEO

ITEMS INCLUDED IN YOUR TOUCHLESS MIST SANITIZER

Touchless Mist Sanitizer
PART A



Sanitizer Tank
PART B



Tank Insert
PART C



Cotton Wick
PART E



Spring
PART D



Charger
PART F



STEP 1

Remove clear plastic base on the bottom of PART A. Twist counterclockwise to open.




STEP 2

Remove all of the items stored inside of the base (Includes PARTS C, D, E, & F).



STEP 3

Remove PART D and PART E from the small ziplock bag. Hold PART C upright as shown. First insert PART D (spring) into PART C with the closed coil side facing upwards. After, place PART E (wick) on top of PART D (spring). The wick should bounce on top of the spring when placed inside of PART C.



STEP 4

Remove black cap from PART B (sanitizer tank). Then place fully assembled insert from step 3 (PART C) into the sanitizer tank (PART B).



STEP 5

Twist the white top portion of the device (PART A) onto the fully assembled sanitizer tank (PART B).



STEP 6

Take the clear plastic piece of PART A and place on the bottom covering the tank. Twist clockwise until the clear bottom locks into place.



STEP 7

Unravel charger (PART F). Insert the small end into the charging port located above the logo 'only 1 way to insert'. Take the USB end and insert into a charging cube or USB charging port. Charge device overnight (6-8 hours). The tiny red blinking light below the logo on back indicates charging.



STEP 8

After fully charging, double click the power button to turn the device on. Hold your hand above the device until it dispenses a fine mist of sanitizer.

When turning off, hold down the power button for 3 seconds. Charge nightly for best use.



NEED ASSISTANCE?

Unit does not respond. No power.

- Plug device into power with provided USB charging cord. Charge for 6-8 hours (tiny red blinking light indicates charging).
- To power on, 'double-click' rapidly. Do not delay between clicks. If double click does not do the trick, hold power button until LED light appears.

Unit does not spray.

- Ensure spring is properly in place – Take out the cartridge & check to see if spring is below white wick. Make sure the wick bounces freely up & down on top the spring when touched. If not, try reversing the direction of spring.
- Make sure unit has charged overnight.

Unit sprays continually.

- Spring may be stuck – Remove cartridge & check that the wick is bobbing freely on the spring & is not stuck. If stuck, remove wick & pop out spring, then replace properly.
- Sensor on top may be blocked – Ensure nothing is blocking the silver circle or either of the 2 sensors on top. Gently wipe the top with soft cloth dampened with Windex or warm water.

844.402.4348