

CAUTION

- TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER.
 - THERE ARE NO SERVICEABLE PARTS INSIDE.
- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.



The lightning flash with arrow-head symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the unit's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.

IMPORTANT SAFETY INSTRUCTIONS

All of the safety and operating instructions should be read, adhered to and followed before the unit is operated.

WARNING

- Close supervision is necessary when this appliance/ product is used by or near children or mentally disabled individuals.
- Use this unit only for its intended use as described in this manual.
- Unplug this unit during lightning storms or when unused for long periods of time.
- 4. Never drop or insert an object into any opening.
- 5. The unit should be situated away from direct sunlight or heat sources such as radiators, electric heaters, heat registers, stoves, or other units (including amplifiers) that produce heat. Avoid placing on top of stereo equipment that radiates heat.

TABLE OF CONTENTS

Warnings and Cautions
Location of Parts and Controls
Installing the Batteries
Using the AC Adapter
Using the Mirror
Using the Night Light with AC Power
Using the Night Light with Battery Power10
Care and Maintenance
Specifications
You May Also Like12

SAFETY AND HANDLING INFORMATION

For maximum product life, do not drop, throw, or crush the mirror. Do not expose it to humidity, dust, or operating temperatures outside 32°F to 113°F (0°C to 45°C).

SAVE THESE INSTRUCTIONS!

DANGER

To reduce the risk of electric shock, burns, fire or injury:

- 1. Do not use while bathing or in a shower.
- Do not place or store unit where it can fall or be pulled into a tub or sink.
- Do not place in, drop or submerge in water or other liquid.
- Do not reach for a unit that has fallen into water. Unplug it immediately.
- Care should be taken so that objects do not fall and liquids are not spilled onto the unit.

2

1

- Never block the air openings of the unit with materials such as clothing, plastic bags or papers, or place it on a soft surface such as a bed or couch, where the air openings may be blocked.
- Never operate this unit if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water. If the unit's power supply cord or plug is damaged, do not attempt to fix it yourself.
- To avoid the risk of electric shock, do not disassemble or attempt to repair the unit. Incorrect repair can cause risk of electric shock or injury to persons when the unit is used.
- Do not operate in the presence of explosive and/or flammable fumes.

BATTERY PRECAUTIONS

- Dispose of the old batteries properly. Do not dispose of the old batteries in a fire.
- Do not leave the batteries where a child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- The batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of the required size and type.


5

LOCATION OF PARTS AND CONTROLS

10. 5X Magnifying Mini Mirror

12. Holes for Suction Cups

11, Suction Cups For Attaching Mini Mirror (x2) 13. USB Cable




USING THE MIRROR


- Touch the light bulb icon on the lower face of the mirror to activate its light.
- 2.) Touch the wind icon on the lower face of the mirror to active its fan.

Note: Both of these features only work when the mirror is either pluged into a power source, or has working batteries.

LOCATION OF PARTS AND CONTROLS

- 1. Mirror
- 2. LED Ring
- 3. Holding Tray
- 4. Light Touch Sensor
- 5. FanTouch Sensor
- 6. Fan Ventilation
- 7. Flexible stand
- 8. USB Connection
- 9. Battery Compartment & Cap. It Takes 3 AA Batteries (Not Included)





6

INSTALLING THE BATTERIES

- 1. If the mirror's tray is attached to the neck, twist the cap under the tray off, before removing the tray, revealing the battery compartment. DO NOT LOSE THE CAP.
- 2. Insert 3 AA batteries (with the positive side turned up toward the cap) into bottom barrel of mirror's neck.
- 3. Twist the tray back onto the bottom of the mirror's neck, then reapply the cap, also by twisting it. Use caution when twisting so as not to break the plastic by twisting it too tight.

USING USB CABLE

- 1. Connect small end of USB cable to the input located on the back of the mirror.
- 2. Plug the larger end of the cable into a USB outlet such as can typically be found on a computer, or a phone charger.

DISCLAIMER NOTICE:

In the process of the preparation of this manual, we have sought to make the content correct and complete. However, there is no guarantee that there are no errors or omissions in the manual. We reserve the right to change specifications of the products mentioned in this manual at any time without prior declaration. No part of this manual shall be reproduced, transmitted, transcribed or stored in a searchable system or translated into any other languages without the written authorization of our company. The company is not responsible for the loss caused by non-standard or wrong operation.

WARRANTY:

- Damage caused by failure to follow the instructions, human factors, force majeure, etc. is not covered by warranty.
- Maintenance cost will be charged for product out of warranty.
- You can register for your free warranty on www.IGIA.com. CUSTOMER SERVICE

Phone: (516)-653-0666

Email: OnlineOrders2017@gmail.com

www.IGIA.com

CARE AND MAINTENANCE

- · Wipe housing with a soft, dry cloth.
- Do not use abrasive cleaning agents.
- · Clean mirrors with a glass cleaning solution.
- Do not spray cleaning solution directly onto glass.

7