


# Instruction for timer

## I. Functional features

You can set countdown of day, hour, minute and second up to 999 days, 23 hours, 59 minutes and 59 seconds. When the set time is up, the screen will flash and ring for 60 seconds. The device can also be used as a timer.

## II. Diagram



## III. Instruction for the keys

SET: enter setting, switch, confirm, lock.  
UP/S: increase value, start, pause

## IV. Instruction for operation

1. Timer: when the timer shows 000 00 00 00, press UP/S to start timing and press UP/S again to pause timing. Repeatable pause and cumulative timing are allowed. Reset the timer by pressing SET and UP/S at the same time.
2. Countdown: Long press SET for 3 seconds, the "second" will flash. Press UP/S to increase the value. Press SET, the "minute" will flash. After setting second, minute, hour and day, press SET to confirm. Press UP/S to start countdown and press UP/S again to pause countdown. Repeatable pause and cumulative timing are allowed. Reset the timer by pressing SET and UP/S at the same time.
3. Press SET 3 times consecutively after the timing/countdown starts. Press SET 3 times to unlock it.

## V. Tips

1. Keep dry.
2. Avoid contact with corrosive objects.
3. Do not expose in the sun for a long time or under glaring light.
4. Please replace the battery when the display is dim or when there is no display at all.