

# AIRCANDY

## ILLUMINATED

### INFLATABLE LED BLOCHAIR



#### INSTRUCTION & CARE MANUAL

IMWM255

#### GETTING TO KNOW YOUR AIRCANDY CHAIR

Congratulations on your purchase of the AirCandy Inflatable Chair. It is comfortable, durable, and fully adjustable. Manufactured with heavy-duty PVC and 100% waterproof, the AirCandy Inflatable Chair is ideal for use both indoors and outdoors.



Please inflate for your own comfort as it does vary from person to person. A full inflation will make the chair very firm and a slightly lower inflation will provide a beanbag-effect, allowing you to sink into the chair. Please use caution to not overinflate the chair.

#### HOW TO USE THE LIGHTS ON YOUR BLOCHAIR

##### HOW to USE

Press the top button on the compartment to turn on. The product features 3 light modes.

- MODE 1** – FAST CYCLE
- MODE 2** – SLOW CYCLE
- MODE 3** – ALWAYS ON

##### BATTERY INSTALLATION

1. Remove water-resistant cap by unscrewing it counter-clockwise
2. Slide the expired batteries out of the compartment
3. Insert 3 new AA batteries, making sure to follow the polarity as marked inside the compartment.
4. Insert the battery cartridge back into the housing.
5. Screw the cap back on – do not over-tighten.

#### INFLATING & DEFLATING YOUR AIRCANDY CHAIR

Preparation of your inflatable chair requires no tools. However, we recommend using a pump for easiest set up.

There are two nozzles on the bottom of the chair that need to be inflated. The outer nozzle controls the outer area of the chair and the inner nozzle controls the seat.

Please inflate for your own comfortability as it does vary from person to person. A full inflation will make the chair very firm and a slightly lower inflation will provide a bean bag type effect allowing you to sink into the chair. Please use caution to not over inflate the chair.

**NOTE:** For best performance in the water, reduce the air in the chair to in order to bring your body closer to the water level. At night time, prepare for an amazing experience with your Illuminated Chair.

#### LIMITED 30-DAY WARRANTY

B&D Group, LLC, warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 30 days from the date of purchase. If any such defect is discovered within the warranty period, B&D Group, LLC. will repair or replace the unit free of charge upon receipt of the unit, shipping postage prepaid and insured to the factory address received from Customer Service. The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. Removal of any panels voids all warranties. This warranty does not cover cost of repairs made or attempted outside the factory. Any applicable implied warranties, including warranties of merchantability and fitness are hereby limited to 30 days from the date of purchase. Expressed or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not

#### WARNING:

Adult supervision required for inflation, deflation and maintenance. Follow all safety instructions to avoid serious injury.

- For household/residential use only.
- This chair is not intended for infants or persons with limited mobility.
- Place the chair in a safe area before use, making sure that there are no sharp edges, steps, drops, or breakable items nearby.
- Use on flat surfaces only. Do not use this chair on abrasive surfaces or near sharp or pointed objects.
- Keep this chair away from heaters, flames, sparks, or any heat source.
- Do not use this chair while using hot or sharp objects.
- Store your chair in a clean dry place at room temperature (above 50°F/10°C). Storing your Chair under 50°F (10°C) and over 100°F (38°C) may affect its performance and will not be covered under warranty.
- Do not jump on the chair.

#### CAUTION:

Do not place on rough ground or near sharp objects as this may cause damage to your chair.

#### LIMITED 30-DAY WARRANTY

apply. The only authorized service center in the United States would be communicated from Customer Service. Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter detailing the complaint or issue, along with your daytime telephone number, name and address inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to Service@BandDGroup.com, specifying the model number and the problem.

PLEASE DO NOT SEND YOUR UNIT WITHOUT RECEIVING AN ESTIMATE FOR SERVICING. WE CANNOT STORE YOUR UNIT.



#### Care, Maintenance & Storage

1. Inspect your chair prior to each use.
2. Keep your chair away from sharp objects. Large cuts or snags may not be repairable and will not be covered by your warranty.
3. In case of incidental damage to your chair, a repair kit has been included. Please follow repair instructions carefully as shown on the patch.
4. To clean your chair, use soap and water with a wash cloth.  
For covered chairs, please follow care instructions on the sewn-in label.
5. To store your chair, make sure it is deflated and completely dry. Store your chair in a clean, dry place at room temperature.

#### Service

For Customer Service or if you need to service your product please email: Service@BandDGroup.com. Please note the product model number, your name and phone number in the email message.

#### Legal

AirCandy is a trademark of B&D Group, LLC.  
Distributed by B&D Group, Miami, FL. ©2022-2023. All rights reserved.

MODIFICATION NOT APPROVED BY B&D GROUP, LLC. VOIDS WARRANTY.  
ACTUAL PRODUCT MAY VARY SLIGHTLY FROM PHOTOGRAPH.

www.BandDGroup.com

IMWM255

MADE IN CHINA