IMPORTANT SAFETY INSTRUCTIONS

INSTRUCTIONS PERTAINING TO THE RISK OF INJURY TO PERSONS:

Please read the instructions carefully before use

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

- 1. Do not attempt to disassemble and repair the product yourself.
- 2. To avoid damage to your eyes, do not look directly at light source.
- 3. Waterproof level IP65, adapter only is IP44.

ASSEMBLY INSTRUCTIONS:

- 1. Remove all parts from packing material.
- 2. Insert cable part (F) onto the cable end marked (G) as shown in Diagram (C), and screw the cover (G) onto (F) and tighten.
- 3. Insert the other end of the cable (D) onto the cable end marked (C) as shown in Diagram (B), and screw the cover (C) onto (D) and tighten.
- 4. Insert the adapter (A) onto the cable (B) as shown in Diagram (A) and screw the cover (B) onto (A) and tighten.
- 5. Plug the adapter into the outlet.
- 6. Use the push button 3-way switch (E) on the cable to enjoy.
 - Push#1 Yellow light for Mosquito repellent.
 - Push#2 White light for decorative lighting.
 - Push#3 Whole string turns off.

CLEANING AND STORAGE

- Always make sure the device is turned off before cleaning.
- 2. To clean, use a soft cloth.
- 3. Do not use any chemical or abrasive cleaners.




Diagram B



Diagram A

Diagram C





