ethohome®

ethohome®

(CE) (FC) **RoHS**

PACKING LIST | ☑ Anti gravity water drop clock   ☑ Type-c power cord   ☑ User Guide

ethohome®

ANTI GRAVITY
Water Drop Clock

User Guide

Important Informations

- **WATER LEVEL DETECTION & DRY BURN PREVENTION SENSOR**
  Anty gravity water drop clock features water level sensor. If the water level is too low, clock will turn off and prevent dry burn.

Warning

- This product is not suitable for children to use alone. Adult supervision is required. Please place this product where it is inaccessible to infants.
- **PROHIBITED:** Do not put this product in water or other liquids. The internal structure of the product is complex, and no nonprofessional should disassemble the product without authorization.

Important

- Before using this product, please ensure that the water inside the tank is at a sufficient level.
- Please place the product vertically to ensure the best effect of water droplets while using it.
- Please use the adapter with the corresponding power.
- **DO NOT** use socket or the USB interface on the computer, that current is insufficient. Use power source that is at least 5V 2A, but not greater than 10V 4A. The motherboard can be damaged if the maximum current and voltage are exceeded.
- Best practice is to use mineral water. Do not add alcohol perfume or any additives that are not essential to the product use.
- Since the air in the water pipe is not fully discharged, it is normal for the water droplets to delay forming at the start. The delay time is about 30 to 60 seconds.
- After the product has been on for some time, it will be normal for the top of the product to warm up.
- Please use a clean, soft cloth to wipe the product.

Product Introduction

01. **Spray Outlet**

02. **Set Time (M)**

03. **Power Button**

04. **Add Time (+)**

05. **Led Screen**

06. **Led Bulb**

07. **Water Outlet**

08. **Silicone Antiskid Pad**

INSTRUCTIONS:

STEP 1: ADD WATER

Standard metod-Unscrew cover and add water to the water tank. Reattache cover.

Quick metod-Add water directly in water outlet without unscrewing cover.

STEP 2: TURN ON

Connect adapter to the USB port or a power source and press power button.

STEP 3: SET TIME

Press **M** to switch from hour to minute, and then press **+** to add time.

Product Color:	**Black**	Voltage:	**5V**
Material:	**ABS + Silicone**	Power Source:	**USB Type C**
Water capacity:	**800 ML**	Weight	**0.99lbs** (450g)
Noise:	**<36db**	Working hours:	**8-10hours**

Dimensions: **4.7" x 4.7" x 9"** (120mm x 120mm x 231mm)