

IMPORTANT SAFETY INSTRUCTIONS

INSTRUCTIONS PERTAINING TO THE RISK OF INJURY TO PERSONS:

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

1. Turn off/unplug and allow to cool before cleaning or other maintenance.

2. Do not look directly at lighted bulb.
3. Keep lamp away from materials that may burn.

4. Do not remain in light if skin feels warm.


ASSEMBLY INSTRUCTIONS:

1. Lay out all parts on a smooth surface as shown in illustration.


2. Push the button to install the shade as shown FIG(1) FIG(2).
3. Insert the male plug of adapter into the female jack at the end of the wire.

4. Plug the adapter into the outlet.

LAMP SIZE



PARTS & DESCRIPTION




SPECIFICATIONS


MODEL	POWER	LUMEN	CRI	INPUT	SIZE(L*H)
PA005-2	12W	750-800LM	RA>95	12V 800mA	60*35*21CM

HOW TO MOUNT THE LAMP BAR

STEP 1 INSTALL THE BAR



STEP 2 CONNECT 12V INPUT




DC 3.5

Please mount and uninstall the screen bar lamp as above shown.

PLEASE PULL THE BUTTON

STEP 3 UNINSTALL THE BAR



FIG(2)

NOTE:

This lamp uses specially formulated LEDs that simulate the characteristics of the sun. The light will appear brighter and whiter compared to a normal incandescent bulb and will provide many of the benefits of natural sunlight. In addition, these LEDs are energy efficient and eco-friendly. They are not replaceable.

Manufacturer Info: info@daylight24.com/978-494-6324

FIG(1)

daylight24®

natural daylight anytime

SAVE THESE INSTRUCTIONS

HOW TO USE:

USAGE SUGGESTIONS

PIANO



OFFICE/DESK



MAINTENANCE:

1. To clean, use a soft cloth.
2. Do not use any chemical or abrasive cleaners.

SAVE THESE INSTRUCTIONS

ILLUMINANCE PARAMETER

ILLUMINANCE (LUX)			
WORKING HEIGHT	6500K DAY LIGHT	4000K NEUTRAL LIGHT	3000K WARM LIGHT
30CM	3260LUX	2940LUX	2490LUX
40CM	2050LUX	2030LUX	1572LUX
50CM	1453LUX	1328LUX	1140LUX
70CM	803LUX	735LUX	634LUX


\*Notes: Power=12w

NO GLARE , GOOD FOR EYES!



1. An ordinary light positioned above your head can reflect light from a shiny surface or shine directly into your eyes.
2. The piano light has a special luminous angle of 45 degrees protecting your eyes from any direct glare.

HOW TO USE THE BUTTON



- Touch on/off switch:** Touch once to turn on/off.
- Light sensor switch:** Touch once to adjust the light intensity automatically according to the environment. When the small indicator light turns green, the function is operating.
  1. Touch once to turn the function on or off.
  2. When the function is operating, the lamp will auto-adjust:
    - When the environment turns bright, the light turns dark gradually.
    - When the environment turns dark, the light turns bright gradually.
  3. To stop this function:
    - Touch the light sensor switch again.
    - Touch the dimmable switch.
- CCT Change:** Touch the button for 3 seconds to start stepless color temperature change or quick touch to change the color temperature from 3000k to 4000k to 5000k to 6500k.
- Dimmable:** Touch the button for 3 seconds to start stepless dimming or quick touch to change the brightness levels from 10% to 25% to 50% to 70% to 100%.