


# VERTICAL CHIPPING PRACTICE NET

Item No. 208890

## USER GUIDE

Thank you for purchasing the Vertical Chipping Practice Net. Please read this manual thoroughly before operating this device.

## PARTS



## INSTALLATION STEPS


### Step 1:

- Connect A and B together by placing A on top and B on the bottom.
- Insert the straight tube by aligning the push pin with the corresponding hole on the tube and pressing it in place.




## Step 2:

- Connect the assembly structure from Step 1 to part C.
- Open the Velcro on the back of part C and attach it to the structure assembled in Step 1.



## SETUP

The assembled net can be set to 4 different angles using the push pins.



## WARRANTY AND CUSTOMER SERVICE

This item from SharperImage.com includes a 1-year limited replacement warranty. If you have any questions not covered in this guide, please call our Customer Service department at 1 (877) 210-3449. Customer Service agents are available Monday through Friday, 9:00 a.m. to 6:00 p.m. ET.

**SHARPER IMAGE®**

The SHARPER IMAGE® name and logo are registered trademarks.

©Sharper Image. All Rights Reserved.