



How to set the new combination:

The default combination is 0-0-0. To set your own combination, please follow these steps:

1. Press the top button to spring open the lock.
2. Set the combination resetter from Fig A to Fig B.
3. Set your desired personal combination by turning the dials.
(for example, 8-8-8)
4. Set the combination resetter from Fig B back to Fig A to complete the resetting.

Please write down your combination and put it in a safe place.

How to use the lock

1. Put the lock over the stopper as the right figure shows. Lock the lid and scramble the dials to lock it.
2. Turn the dials, align the number to the middle convex line. To the button to open the lock.

