



GIGANTIC T-REX SPRINKLER

INSTRUCTION MANUAL



GIGANTIC T-REX SPRINKLER

Model #: PC3302TR

PoolCandy
www.PoolCandy.net
service@banddgroup.com

B&D Group, LLC
Miami, FL 33186
USA



WARNING!

- This product is intended to be used as a toy and not a flotation device.
- Adult supervision is required at all times.
- Do not leave child unattended while in use.
- Not for use on water.
- Keep away from fire.
- Do not place on sharp or jagged surfaces.
- Responsible adults should instruct children on proper use of this toy.
- This is not a lifesaving device.
- Do not overinflate.



WARNING!




**CHOKING HAZARD – SMALL PARTS,
NOT FOR CHILDREN UNDER 3 YEARS.
ADULT ASSEMBLY REQUIRED!**

How to Inflate

1. Open the air valve. Use an air pump to inflate.
2. Close the air valve quickly.
3. Your unit may include more than one air valve.

Fill all chambers before use.


- DO NOT overinflate.
- DO NOT use a high-pressure pump to inflate.



How to Use the Sprinkler

1. Attach a garden hose to the sprinkler by rotating the connector.
2. Turn the water on low, and adjust the pressure as needed.

NOTE: The rubber gasket inside the connector is required to prevent water leakage.



Storage and Care

1. Open the air valve and deflate completely when not in use.
2. Dry the item completely before folding and storing.
3. Keep in a dry place until next use.

LIMITED 30-DAY WARRANTY

B&D Group, LLC, warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 30 days from the date of purchase. If any such defect is discovered within the warranty period, B&D Group, LLC, will repair or replace the unit free of charge upon receipt of the unit, shipping postage prepaid and insured to the factory address received from Customer Service. The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. Removal of any panels voids all warranties. This warranty does not cover cost of repairs made or attempted outside the factory. Any applicable implied warranties, including warranties of merchantability and fitness are hereby limited to 30 days from the date of purchase. Expressed or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply. The only authorized service center in the United States would be communicated from Customer Service. Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter detailing the complaint or issue, along with your daytime telephone number, name and address inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to Service@BandDGroup.com, specifying the model number and the problem.

PLEASE DO NOT SEND YOUR UNIT WITHOUT RECEIVING AN ESTIMATE FOR SERVICING. WE CANNOT STORE YOUR UNIT.