




Attaching Easy-Ride to your bicycle using the quick release mechanism






To open the locking mechanism pull the outer shaft towards you.

Insert the male fitting into the shaft as instructed in pictures 1-4.



Releasing the outer shaft will lock Easy-Ride to your bicycle frame.



To remove Easy-Ride from your bicycle frame, pull the outer shaft towards you and remove EasyRide from your bicycle.

Adjusting the leash length




Easy-Ride's adjustable leash, allows you to easily adjust the leash's length to fit your needs.

Shorten the leash before riding on your bicycle. Allow the leash to be long enough to enable your pet to move around your bicycle.


For long walks in open spaces, disconnect the leash from the Easy-Ride shaft and adjust its length.




Installation instructions




1. Take the rubber grip with the two stickers. Remove sticker cover stick on the bicycle shaft




2. Wrap tightly around the shaft.




3. Use the sticker on the other side of the rubber to secure the grip on the shaft




4. Assemble Easy Ride using the bolts and Allen key provided. Close tightly on the rubber grip.



* Notice the angle of the rotating connector. The rotating connector must point upwards in order to ensure that the EasyRide rotating shaft is parallel to the ground.

Incorrect 



Correct 

