

Lumbar Support Instruction Manual

1. Product display

Interface type: USB


Voltage/current: 5V/4.5-7.5W

Fabric material: double-layer hollow ice mesh

Note: Because the USB interface of some cars and computers is a data interface, the output current is only 0.5-1A, and our ventilation depends on the required current of 2A. If the wind power is not enough when plugged into this type of interface, you can use a power bank or a mobile phone. Charging PD head.




Front




Back

2. Product installation



After the lumbar support is put in place, use the elastic bands on the left and right sides to wrap around the seat is tied up




(1) While holding down with one hand, adjust (2) the length of the upper and lower straps with the other hand to obtain the desired lumbar curvature



WeChat scan code
Watch the installation video

3. Product use

1. Plug in the power supply, short press the switch to turn on
2. Short press the (1) switch one by one to switch.
Low-grade,
mid-grade③,
high-grade④
3. When not in use, it is recommended to turn off manually



4. Washing instructions

First remove the fan behind the lumbar backrest, and then rinse it directly with clean water



1. Open the metal buckle of the fan casing



2. Rinse after taking out the fan