


# Glow Decor Instructions

1. Power with 3 “AA” batteries **OR** use included USB cable to plug into USB socket, adapter or power bank.  
(If powering by USB, do not install batteries.)
2. Slide switch to “on” position.
3. To use remote, first remove plastic tab, point at print.  
To replace battery CR2025 see diagram on remote.



4. Care Instructions: Remove AA batteries when not in use.  
Clean with a soft, dry cloth or duster. Indoor use only.  
Do not hang in direct sunlight.



[WWW.GLOWDECOR.COM](http://WWW.GLOWDECOR.COM)

