



Dona Gelsinger

Artwork by © Dona Gelsinger

SWITCH INSTRUCTIONS

OFF - LIGHTS AND MUSIC OFF

ON - LIGHTS, MUSIC ON (NO TIMER)

LIGHTS ONLY - LIGHTS ON, MUSIC OFF, TIMER ON 6 HRS

**MUSIC ACTIVATED BY LIGHT/MOTION SENSOR OR
PRESS BUTTON ON FRONT, LOWER RIGHT CORNER.**

**REQUIRES 3 - AA BATTERIES, NOT INCLUDED
REMOVE BATTERIES WHEN NOT IN USE OR DISCHARGED**

MADE IN CHINA

TSCA Title VI Compliant - Manufactured 05/2023

NOT A TOY, DECORATIVE USE ONLY



A2227
MUSICAL GNOME