

## MILEX ADJUSTABLE BOOK HOLDER STAND INSTRUCTION MANUAL:



Press the button in the middle of the joint to rotate and fold the bracket.

Release the button to lock it.


There is a triangular arrow on each button.

The arrow points are marked with degrees.

The joint scale is 15 degrees.

Only when the left and right bracket legs are folded at the same angles can the bracket be used smoothly (see the reference pictures for the folding angle).

### 2. Folding angle reference diagram (left view)



### 3. Adjustable Paper Clips

Use the Adjustable Paper Clips to hold Book or pages in place