

ITEM NUMBER: **54283 54283X** 



⚠ WARNING:
CHOKING HAZARD--Small parts.
Not for children under 3 yrs.

Made In China Franklin Sports Inc. Stoughton, MA 02072



For replacement parts: Visit: www.franklinsports.com/54283 Email: parts@franklinsports.com Call: 1-800-225-8649



# **CUSTOMER SERVICE COMMITMENT**

Thank you for purchasing this Franklin® product! In the event that the product you've purchased has missing or damaged parts, please contact us at:

parts@franklinsports.com

Visit our website at: www.franklinsports.com/54283

If possible, please include product part number and parts description so we can best assist you.


# **WE'RE HERE FOR YOU!**

PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE IT WAS PURCHASED FROM.

**WE ARE COMMITTED TO FULFILLING ALL** REPLACEMENT PART NEEDS IMMEDIATELY.

Thank you for your continued support, and welcome to the #FranklinFamily!


## **PARTS LIST**




### **ASSEMBLY INSTRUCTIONS**


#### - GENERAL NOTE —

- 1. Find a clean place to begin the assembly of your Pro Hoops Basketball Game.
- 2. Remove all the parts from the box and verify that you have all of the listed parts as shown on the parts list page.
- 3. Before assembling the set, remove the protective film from the front of the backboard.






NOTE -Attach the Hooks (#6) to the Main Board (#1) using four M4 Metal Bolts (#3) and four M4 Metal Nuts (#4). Stick the Protective Foam (#13) to the inside faces of the hooks.




**Franklin**\* ITEM#: 54283 54283X




Attach the Rim (#7) and Ball Return (#11) to the Backboard (#1) using two Bolts (#5), one Metal Support (#2) and two Nuts

NOTE -

NOTE: THE BALL RETURN SHOULD BE BETWEEN THE RIM & THE BACKBOARD.






#### NOTE -

Install the Net With Elastic (#8) to the Rim (#7) then stretch the elastic around the opening of the ball return.

## NOTE DO NOT CUT **ELASTIC IN NET**



#### PARTS NOTF -Unscrew the battery compartment to insert batteries.

Screw battery

compartment closed.

#### NOTE

Requires 4 "C" size batteries (not included) Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

## **GAME INSTRUCTIONS**

#### Rules:

Pro Hoops Basketball by Franklin is designed to be played inside and is a fun twist on some of our other basketball games. Players are trying to reach a score of 21. Players choose who will be shooting first. The player first up to shoot will choose the location their first shot will be thrown from. This location will be the same location used by all the other players and their first shot. When a player scores a point, they will choose the next location to shoot from and they will be the first ones to shoot.

#### Scoring:

Each time the ball is landed in the net, it is a potential one point. Players are able to snag points from one-another. For example, if there are three players (A.B.C) and player A chooses the shot location. shoots the ball and the ball goes through the net they have scored one point. However, the following two players (B,C) have a chance to snag player A's point. To do this, player B will shoot the ball from the same location that A did. If player B gets the ball through the net, then player B will snag player A's point. When this happens, player C now has the chance to steal player B's point. If both players B and C miss when trying to steal player A's point, player A will score 1 point. In the case that no players score points the person that shot first may choose another location to shoot the next round from. Players will play until one of the players reach 21.

## **YOU ARE NOW READY TO PLAY!**