

# hearthsong™

## Stargazer Play Tent

### Safety and Assembly Instructions


#733900 | Ages 3+

**Adult assembly required.**


Takes 1 adult to assemble.

3½' diam. x 4½'H

### Parts Included:



**A** x 1 Collapsible play tent



**B** x 4 Tent poles




**C** x 1 String of moon & star LED lights





**D** x 1 Carrying bag

**Assembly:**




**Care:** Spot clean.

**Use:** DO NOT ALLOW ANYONE UNDER THE AGE OF 3 TO PLAY IN THE TENT.




Long end of  
tent pole




## After Use:




Scan to watch  
how to collapse  
for storage!




Remove and collapse tent poles  
and lights; flatten tent.



Grasp flattened tent at opposite  
ends.



Twist into a figure-8. Collapse  
tent poles, neatly roll up string  
lights and store in carrying bag.



Fold two halves and flatten for  
storage.

## Lights take 3 AA batteries (not included).

### IMPORTANT BATTERY INFORMATION



- Battery installation and removal should be performed by an adult.
- Use only batteries recommended in this instruction manual.
- Be careful to install the batteries with the correct polarity, as indicated.
- Do not mix old and new batteries; remove all batteries when replacing.
- Do not mix alkaline, standard (carbon-zinc), rechargeable (nickel-cadmium), or any different types of batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged and are only to be charged under adult supervision.
- Only batteries of the same or equivalent type are to be used.
- The supply terminals are not to be short-circuited.
- Always remove weak or dead batteries from the product.
- CAUTION: Do not dispose of battery in fire. Battery may explode or leak.



Battery must be recycled or disposed of properly.  
Do not short-circuit or dispose of in fire or landfills.

## Need a Hand?

We're here to help! For questions regarding assembly, product maintenance and care, please reach out:

- Email: [Happy@Hearthsong.com](mailto:Happy@Hearthsong.com)
- Phone: 1-800-533-4397
- Direct message us on social  

We'll work together to ensure your best experience!

*Complete policy at [Hearthsong.com>Returns](https://www.hearthsong.com>Returns)*



**WARNING:** KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC—This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.