

INSTRUCTION MANUAL

Congratulations on your purchase of your PoolCandy® Illuminated LED Pool Basketball featuring LiveLights Technology—the perfect accessory for any pool or beach party!

HOW to USE

Press the top button on the compartment to turn on. The product features 3 light modes.

MODE 1 FAST

MODE 2 SLOW

MODE 3 ALWAYS ON

BATTERY REQUIREMENTS

This product requires 2 x CR2032 batteries, included.

BATTERY INSTALLATION

- 1. Remove water-resistant cap by unscrewing it counter-clockwise
- 2. Slide both expired batteries out of the compartment
- Insert 2 new CR2032 batteries, making sure to follow the polarity as marked inside the compartment
- 4. Insert the battery cartridge back into the housing.
- 5. Screw the cap back on-do not over-tighten.

▲WARNING!

CONTAINS BUTTON OR COIN CELL BATTERY. HAZARDOUS IF SWALLOWED.

▲WARNING!

THIS PRODUCT CONTAINS A BUTTON OR COIN CELL BATTERY. A SWALLOWED BUTTON OR COIN CELL BATTERY CAN CAUSE INTERNAL CHEMICAL BURNS IN AS LITTLE AS TWO HOURS AND LEAD TO DEATH. DISPOSE OF USED BATTERIES IMMEDIATELY. KEEP NEW AND USED BATTERIES AWY FROM CHILDREN. IF YOU KNINK BATTERIES MIGHT HAVE BEEN SWALLOWED OR PLACED INSIDE ANY PART OF THE BODY, SEEK IMMEDIATE MEDICAL ATTENTION.

Do not mix Old and New batteries.

Do not mix Alkaline, Standard (Carbon-Zinc), or rechargeable (Nickel-Cadmium) batteries.



NOTICES, CAUTIONS & WARNINGS

AWARNING:

This product contains flashing lights, which can cause seizures, headaches, dizziness, and/or other chemical problems in certain individuals. Caution should be exercised when using this product, particularly around people who have adverse reactions to flashing lights.

FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CARE & HANDLING

- Includes a Patch Kit
- Do not submerge the product in any liquids other than water
- . Keep unit dry when not in use
- Do not place product near powerful, unshielded magnets
 Do not expose the product to extreme hot or cold temperatures
- . Do not jump into the product

- Do not cut, poke, or try to disassemble the product for any reason
- Do not drag the product on a hard or abrasive ground as it may puncture the inflatable
- Do not adhere or apply any hardware or attachments to the product not recommended by the manufacturer

BATTERY HANDLING INFORMATION

- Non-rechargeable batteries are not to be recharged
- Rechargeable batteries must be removed before recharging
- Rechargeable batteries should only be recharged under adult supervision.
- DO NOT MIX alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium & nickel-metal hydride) batteries
- · Exhausted batteries are to be removed
- Do not mix old and new batteries
- Do not dispose of batteries in fire; batteries may explode or leak
- Do not dispose of product in fire, batteries may explode or leak
- If this product will not be used for an extended period of time, remove the batteries from the product
- . The supply terminals are not to be short-circuited
- · Batteries are to be inserted with the correct polarity
- Clean the battery contacts and also those of the product prior to battery installation
- · As always, dispose of batteries in an eco-friendly manner

Your PoolCandy inflatable using Livelights technology is water resistant rated to IPX7. This means that it is designed for normal use up to 1 meter deep, please avoid submerging your product any deeper depth.





Made in China • DISTRIBUTED BY B&D GROUP, LLC, MIAMI, FL 33186

If you have any questions or would like additional information on PoolCandy products, please contact us at service@banddgroup.com.