



LED LAWN DARTS

INSTRUCTION MANUAL

ASSEMBLY TIPS

1. Please read the instructions carefully and follow all assembly, operation, or safety instructions in order to avoid damage or injury.
2. Some figures or drawings may not look exactly like your product. Please read and understand the text before beginning each assembly step.

ATTENTION:

1. Check to be sure all contents are included before assembly.
2. Always have adult supervision when assembling or disassembling the product.
3. Check the equipment each time before using it.
4. Do not use the product if you find any breakage.

IMPORTANT:

Remove the plastic insulating tab near the switch in order to activate.
Slide the switch into the ON position – you're ready to play!

BATTERY INFORMATION

- Requires 3 LR41 batteries (each), included.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (Carbon-Zinc), or rechargeable (Nickel-Cadmium) batteries.
- Batteries must be installed according to the correct polarization.

GAME TIP

1. Position the ring targets in a clear area.
2. Space the 2 targets as far apart as you want to play. The distance is up to you.
3. Players or teams take turns tossing the darts underhanded, trying to get the dart to land in the ring.
4. Score a point for each dart that lands in the ring. The team that reaches your selected point total first is the winner!
5. Most important – have fun!

30-DAY WARRANTY

B&D Group, LLC, warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 30 days from the date of purchase. If any such defect is discovered within the warranty period, B&D Group, LLC. will repair or replace the unit free of charge upon receipt of the unit, shipping postage prepaid and insured to the factory address received from Customer Service. The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. Removal of any panels voids all warranties. This warranty does not cover cost of repairs made or attempted outside the factory. Any applicable implied warranties, including warranties of merchantability and fitness are hereby limited to 90 days from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply. The only authorized service center in the United States would be expressly communicated from Customer Service. Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter detailing the complaint or issue, along with your daytime telephone number, name and address inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to Service@BandDGroup.com, specifying the model number and the problem.

PLEASE DO NOT SEND YOUR UNIT WITHOUT RECEIVING AN ESTIMATE FOR SERVICING. WE CANNOT STORE YOUR UNIT.

MANUFACTURED BY B&D GROUP, LLC.

Miami, Florida 33126 • Tel. 305.964.7295