

OUTSIDE LEFT

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.


If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

KeySmart Max contains small parts that could be harmful to young children and pets.

KEY|SMART

OUTSIDE RIGHT



- 1. Expandable**
Fits up to 14 of your existing keys

2. Multi-Tool
Bottle Opener + Flat Head

3. Long Lasting Battery
Up to 60 Days

4. Ultra Bright LED
Helps find door lock at night
- 5. Louder Ringtones**
2x louder than the Pro

6. Rechargeable
With included Micro-USB cable

7. Bluetooth Tracking
150 Foot Bluetooth Range

8. Attach Car Key
With the included keyring

KEY|SMART

FRONT

Hello,

before you add keys to your KeySmart Max let's get it connected to the free Tile™ app.

1

Open the app store on your smartphone and download the Tile™ app.

2

Open the Tile™ app and create your free account.

3

Press the “+” button in the upper left corner and search for “KeySmart” in the list of Tile Enabled Devices.

4

Follow the instructions to pair your KeySmart Max.

Charge Before Use

Before using your KeySmart Max for the first time, make sure to fully charge the battery.

INSIDE LEFT

What's Included



How To Assemble Your KeySmart iPro

Scan the QR code or go to getkeysmart.com/maxassembly and follow the instructions to add up to 14 of your existing key.



How to Use the Flashlight

Press the Flashlight button to turn on and release to turn off. Double-click the Flashlight button to turn on the flashlight for 10 seconds. The flashlight will turn off automatically if pressed for more than 3 minutes to preserve battery life.

KEY|SMART

INSIDE RIGHT

Features of the Tile™ app

KeySmart Max uses the free Tile™ app to provide you with an easy, secure way to locate your keys using your smartphone. If your keys ever goes missing, you can ring them to help track them down around the house or view the last location they were paired with your phone on a map. The Tile™ network is made up of millions of Tile users to help you track down your keys when they're lost.

Scan the QR code go to getkeysmart.com/maxassembly to watch a detailed explanation of the Tile features.



Requirements

To use the Tile™ to locate this item, the latest version of the app is recommended.

Warranty

KeySmart Max is designed to make your life easier. That's why every KeySmart Max is covered under warranty for a one full year against defects in materials and workmanship. To learn more, visit getkeysmart.com/warranty.

Use And Care

The KeySmart Max is water-resistant but not waterproof. We encourage you to bring your KeySmart Max along on most of your wild adventures, but deep-sea explorations (and the like) are not recommended. It is not recommended that you expose the KeySmart Max to extreme hot or cold temperatures.

KEY|SMART

BACK



For instructions in French, German, and Spanish go to getkeysmart.com/maxassembly
Pour obtenir des instructions en français, rendez-vous sur getkeysmart.com/maxassembly
Eine deutsche Anleitung finden Sie unter getkeysmart.com/maxassembly
Para obtener instrucciones en español, vaya a getkeysmart.com/maxassembly

f KeySmart i keysmart y KeySmart