



**THE TIDE MOVES
IN THE PICTURE!**

www.tidepieces.com

TIDEPIECES

Setting Your Tidepieces Tide Clock

You'll need to know the tide times for your location on the day you set the clock. Many newspapers publish this information or you can obtain it using a tide app or at www.noaa.gov. Your clock comes set to "HIGH." You can simply insert a quality "AA" battery into the battery compartment at the time of high tide or you can use the little wheel on the back of the movement to adjust the pointer to the appropriate number of hours to the next tide. Please note that the wheel requires a lot of turns to move the pointer. Note that the tide cycle is not perfectly regular throughout the year, but the irregularity averages out so there is usually no net "error." However, if you want to minimize this irregularity try setting the clock on the day of a full moon.

Use the built-in wall hanger or the included stand!

LIMITED WARRANTY

WARRANTY COVERAGE: THE MANUFACTURER WARRANTS TO THE ORIGINAL CONSUMER PURCHASER, THAT THIS PRODUCT WILL BE FREE OF DEFECTS IN MATERIAL AND WORKMANSHIP FOR A PERIOD OF TWELVE MONTHS FROM DATE OF PURCHASE. THE MANUFACTURER'S LIABILITY HEREUNDER IS LIMITED TO REPLACEMENT OR REPAIR OF THE PRODUCT AT THE MANUFACTURER'S DISCRETION. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, TAMPERING OR OTHER CAUSES NOT ARISING FROM DEFECTS IN MATERIALS OR WORKMANSHIP. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN OPENED OR ATTEMPTED TO BE OPENED BY AN UNAUTHORIZED INDIVIDUAL. THIS WARRANTY EXTENDS TO THE ORIGINAL CONSUMER PURCHASER OF THE PRODUCT ONLY.

Warranty Disclaimers: Any implied warranties arising out of this sale, including but not limited to the implied warranties of description, merchantability and fitness for a particular purpose, are limited in duration to the above warranty period. In no event shall the Manufacturer be liable for loss of use of this product or for any indirect, special, incidental or consequential damages, or costs, or expenses incurred by the consumer or any other user of this product, whether due to a breach of contract, negligence, strict liability in tort or otherwise.

Warranty Performance: In order to be eligible for service during the above warranty period, you must obtain a Return Authorization Number in advance by sending us your name, address, daytime phone number, and Model of your clock, the problem you are experiencing, and the proof of purchase (sales receipt). The repaired or replacement product will be in warranty for the remainder of the original warranty period or for six months, whichever is longer. Other than the charge for postage, no charge will be made for replacement of defective product.

TIDEPIECES CLOCKS ARE WARRANTED TO FOLLOW A SEMIDIURNAL TIDE CYCLE OF 12H 25MIN FROM ONE HIGH OR LOW TIDE TO THE NEXT. THEY ARE NOT WARRANTED TO MATCH AN IRREGULAR TIDE CYCLE AT ANY LOCATION. IF YOU THINK YOUR CLOCK IS OUT OF SYNC BE SURE TO CHECK YOUR LOCAL TIDE TABLE BEFORE DECIDING THAT THE CLOCK IS DEFECTIVE!

For prompt warranty service, repairs, or technical support please contact alan@tidepieces.com directly.