## **Directions**

## Requires 3 - AAA batteries - not included



Step 1. Install AAA batteries. (not included) Insert desired team logo slide and turn on light



Step 3. Carefully remove the red adhesive backing and firmly attach to the cleaned door surface, be sure the light projector is facing down.



Step 2. Identify a flat surface on the inner car door panel. Clean the surface. The LED car door light should be placed vertically and as close as possible to the door edge.



Step 4. Apply the provided silver infrared sticker to the corresponding door sill for better sensor performance. (not required) The LED car door light will automatically light up at night when the car door is open and shut off when the door is closed.