

5" x 5" Trim

BACK

FRONT

INSIDE

Specifications:

- Type: Cordless / Rechargeable
- Watts: 70W
- Average Amps: Average ampere-1A, charging current discharge 6-10A
- Voltage (V) Input 5V – Output 3.7V
- Battery MAH: 1300mAh, 3C power
- Battery Type: 18650 lithium battery
- Battery Life (Max): 400-500 times
- Suction Rating in PA: 2500PA
- Material Breakdown: PP
- Charging Time: Up to 2.5 hours
- Charge Type: USB Type-C cable
- Run Time on Charge: 10 minutes
- Filter Type: HEPA - Washable

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

LIMITATION OF LIABILITY
Liability is limited to the purchase price of this product. Trendstar Corporation shall not be responsible for any incidental or consequential damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. For questions or comments on product please send email to admin@trendstarinc.com. Please allow 48 hours for a response.

CAUTION:

- Do not remove, repair or refit this product unless it is carried out by authorized repair personnel
- Do not over charge or leave unit plugged in after charging
- Do not pick up anything that is hot or burning such as cigarettes or hot ashes
- Do not cover the air vent when operating this product. Unit can over heat and be damaged
- Do not submerge unit in water
- Keep out of reach of children - this is not a toy
- Only use as intended

Model-PVAC

Distributed By:
Trendstar Corporation
Fairfield, NJ 07004
©2023 All Rights Reserved
Made in China

Model-PVAC

Instructions

POCKET VAC
Cordless Handheld Vacuum & Blower

USB
RECHARGEABLE

Clean Up In A Snap!

2-IN-1 Vacuum + Blower



With Vacuum Attachment



With Blower Attachment



Powerful Suction



Powerful Blower



Lightweight Design





Comfortable Grip

Clean up quickly & easily with the charge & go Pocket Vac!

The lightweight hand-held vacuum with strong suction picks up dust, debris, and dirt from the tight areas to larger surfaces. Makes spot-cleaning your home, car, work area a breeze. Use the blower nozzle to instantly blast away dust & dirt from nooks and crannies. Easy charging from any USB power source. The compact design can easily store it in drawers, glove compartment, tool boxes etc.

Includes:



Charging & Use:

USB
RECHARGEABLE



1. Connect the charging cord to fully charge the battery.
2. Indicator light will turn from red to green when fully charged.
3. Use corresponding attachments as needed.
4. Squeeze & hold the power switch to turn on.
5. Store unit and accessories in included storage bag.



Disassembly & Cleaning:

1. Rotate the dust bin counter-clockwise to remove from the unit.
2. Take out the filter in the dust bin and dump the debris into the trash can. The filter can be washed with water and must be thoroughly dried before reuse.
3. If necessary, use a slightly damp cloth or paper towel to clean the dust bin. It must be thoroughly dried before reuse.
4. Reassemble unit and use.

