

PENDULUX

DECO SPEAKER



USE INSTRUCTIONS

Your Pendulux Bluetooth Speaker comes with the speaker component pre-installed in the housing. There is no need to remove the speaker from the housing for normal use. Controls and charging port can be accessed with the speaker in place.



To charge speaker:

- Connect the Micro USB Connector to the Charging Port on the back of the speaker unit
- Connect the USB Connector to a USB port on a wall adapter or to another USB-charging compatible device
- Light will glow while unit is charging and will turn off when fully charged

To connect speaker:

- Press and hold the Power On/Off Button on the speaker
- Put your audio source into Bluetooth pairing mode
- Select the device labeled "M3"
- Use the volume controls on your audio device to increase or decrease volume

PENDULUX.COM