

gemini[®]

At Gemini, our highest priority
is making your experience
unforgettable. Need help setting
up, troubleshooting, or looking
for some tips? We're here for you,
Monday through Friday 9-5PM EST.



1-844-GEMINI9



hello@geminisound.com



www.geminisound.com

Love coupon codes and an
extended warranty?

E-mail us a link to your product
review and we'll send you a coupon
code for our website and extend
your warranty 3 months.

US ONLY

Innovative Concepts and Design LLC
458 Florida Grove Road
Perth Amboy, NJ 08861

gemini[®]

Empower Your Sound



MPA-K650

Portable Karaoke Party Speaker

Index 2
What's Included 2
Features 3
Product Overview 4
Introduction 6
Precautions 6
FCC Compliance Statement 6
Legality & Safety 7
Limited Warranty 8
Return/Repair 8

What's Included

Please ensure that you find these accessories included with your

MPA-K650 speaker:

- (1) MPA-K650
- (1) Microphone with Cable
- (1) Remote Control
- (1) Power Cable
- (1) AUX Cable
- (1) Manual
- (1) Carry Strap

**FEATURES**

- Wirelessly stream music from any Bluetooth device
- Play music from any storage device with built-in USB port, SD Card Slot and AUX Input
- Built-In FM radio with Internal antenna
- 6.5" woofer for big, powerful, clear sound
- Long lasting battery powered speaker with AC charge port
- Wired microphone included with microphone echo control
- AC charging cable included for charging battery or playing
- Remote control Included

MICROPHONE

- Microphone input for the included wired microphone.
- Microphone volume controls.
- Microphone Echo for all your karaoke needs.

POWER

- Volume control and Power switch. Rotate to power on

MIXED MEDIA, TOTAL CONTROL

- AUX input to connect any external device. USB input to play all your favorite tunes.

TAKE IT ALONG YOUR ADVENTURES

- The MPA-K650 features a long-lasting battery and an easy carry strap for maximum portability.

**VOLUME**

Rotate to adjust volume

MIC VOL

Adjust the microphone volume

MIC ECHO

Adjust the echo depth of microphone.

CHARGE

After the power cable is connected, the indicator lamp will be on red color and battery will begin to charge.

FULL

Red LED "Charge" indicator will turn off and Green LED "Full" indicator will turn on when battery is fully charged, unplug the power cable to stop charging

SD CARD/USB

On the top side of the device is an SD card slot. To connect the SD card, push the card completely in the slot until it clicks into place. Just below the SD card slot is a USB port where a USB memory stick can be connected

AUX

Connect 1/8" cable for AUX playback

MIC

Connect microphone with 1/4" cable

MODE

To turn the PLAYER on/off press and hold MODE. Press MODE again to toggle through USB, SD, or Bluetooth as the input device. MODE key is used to switch radio status in order to use radio key-pressing function; if the receiving frequency needs inputting manually, press the numbers on remote control directly to input the frequency of radio station

▶||

Each press of the PLAY/PAUSE BUTTON causes the operation to change from PLAY to PAUSE or from PAUSE back to PLAY.

LED

Press to turn LED party lights on/off

▶▶|

Press to skip to next track or radio station

||◀◀

Press to skip to previous track or radio station

REPEAT

When playing music, Press the key to repeat one or all songs

POWER ON/OFF

Use power switch on front panel to turn speaker ON/OFF

BATTERY DISPLAY

On the display is a battery life indicator with 3 stages: Full charge, Half charge, and Low (blinking)

BATTERY CHARGER

With power cable connected to mains, use the switch on rear of unit to turn charging on/off.

INTRODUCTION

Thank you for purchasing our MPA-K650. We are confident that the Gemini platform of products will not only make your life easier through the use of the latest technological advancements in cross-platform connectivity and sound reproduction but will raise the bar for DJ and pro audio products. With the proper care & maintenance, your unit will likely provide years of reliable, uninterrupted service. All Gemini products are backed by a 1-year limited warranty*.

PREPARING FOR FIRST USE

Please ensure that you find these accessories included with the MPA-k650:

- (1) Power Cord
- (1) Operating Instructions
- (1) Warranty Card

PRECAUTIONS

1. All operating instructions should be read before using this equipment.
2. To reduce the risk of electrical shock, do not open the unit. There are NO USER REPLACEABLE PARTS INSIDE. Please refer servicing to a qualified Gemini Sound Products service technician. Do not attempt to return this equipment to your dealer.
3. Do not expose this unit to direct sunlight or to a heat source such as a radiator or stove.
4. This unit should be cleaned only with a damp cloth. Avoid solvents or other cleaning detergents.
5. When moving this equipment, it should be placed in its original carton and packaging. This will reduce the risk of damage during transit.
6. DO NOT EXPOSE THIS UNIT TO WATER OR HEAT.
7. DO NOT USE CLEANING PRODUCTS OR LUBRICANTS ON THE CONTROLS OR SWITCHES

CONNECTIONS

PLEASE NOTE IT IS VERY IMPORTANT THAT YOUR AMPLIFIER HAS MATCHED POWER RATINGS! (Make sure your equipment is completely OFF and also lower ALL VOLUME, LEVEL, & GAIN controls before connecting the speaker.) Responsible Party Name: Innovative Concepts & Designs

Company address:

458 Florida Grove Road Perth Amboy, NJ, 08861 USA FCC Compliance Statement This device complies with Part 15 of the FCC Rules. The operation is subject to the

following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and then on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to a different outlet so that the equipment and receiver are on different branch circuits.

Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AE6G-MPAK650.

LEGALITY & SAFETY

The device is not intended for use by people (including children) with reduced physical, sensory or mental capacity. People who have not read the manual, unless they have received an explanation by someone responsible for their safety, should not use this unit. Children should be monitored to ensure that they do not play with the device. The device should always be readily accessible. The device should not be exposed to water. No objects filled with liquids, such as vases, shall be placed on the device. Always leave a minimum distance of 10 cm around the unit to ensure sufficient ventilation. Open flame sources, such as candles, should not be placed on top of the device. The device is intended for use only in a temperate climate. At full volume, prolonged listening may damage your hearing and cause temporary or permanent deafness, hearing drone, tinnitus, or hyperacusis. Listening at high volume is not recommended. One hour per day is not recommend either. Danger of explosion if battery is incorrectly replaced or not replaced by the same type or equivalent. The battery should not be exposed to excessive heat such as sunshine or fire. Different types of batteries, or new and used batteries, should not be mixed. The battery must be installed according to its polarity. If the battery is worn, it must be removed from the product. The battery must be disposed of safely.

Always use collection bins to protect the environment. The battery can only be replaced by the maker of this product, the sales department, or a qualified person. Switch the device off where the use of the device is not allowed or where there is a risk of causing interference or danger - for examples: on an aircraft, or near medical equipment, fuel, chemicals or blasting sites. Check the current laws and regulations regarding the use of this device in the areas where you drive. Do not handle the device when driving.

Concentrate fully on

driving. All wireless devices are susceptible to interference which may affect their performance. All our devices conform to international/national standards and regulations, and we aim to limit user exposure to electromagnetic fields. These standards and regulations were adopted after the completion of extensive scientific research. This research established no link between the use of the mobile headset and any adverse effects on health if the device is used in accordance with standard practices. Only qualified people are authorized to install or repair this product. Only use batteries, chargers and other accessories which are compatible with this equipment. Do not connect incompatible products. This equipment is not waterproof. Keep it dry. Keep your device in a safe place, out of the reach of young children. The device contains small parts which may present achoking hazard to kids.

WARRANTY

- A. Gemini guarantees its products to be free from defects in materials and workmanship for one (1) year from the original purchase date. Exceptions: Laser assemblies on CD Players, batteries, cartridges, and crossfaders are covered for 90 days.
- B. This limited warranty does not cover damage or failure caused by abuse, misuse, abnormal use, faulty installation, improper maintenance or any repairs other than those provided by an authorized Gemini Service Center.
- C. There are no obligations of liability on the part of Gemini for consequential damages arising out of or in connection with the use or performance of the product or other indirect damages with respect to loss of property, revenues, of profit, or costs of removal, installation, or reinstallation. All implied warranties for Gemini, including implied warranties for fitness, are limited in duration to one (1) year from the original date of purchase, unless otherwise mandated by local statutes.

RETURN/REPAIR

- A. In the U.S.A. ,please call our helpful Customer Service Representatives at (732) 346-0061, and they will be happy to give you a Return Authorization Number (RA#) and the address of an authorized service center closest to you.
- B. After receiving an RA#, include a copy of the original sales receipt, with defective product and a description of the defect. Send by insured freight to: Gemini and use the address provided by your customer service representative. Your RA# must be written on the outside of the package, or processing will be delayed indefinitely!
- C. Service covered under warranty will be paid for by Gemini and returned to you. For non-warrantied products, Gemini will repair your unit after payment is received. Repair charges do not include return freight. Freight charges will be added to the repair charges.
- D. On warranty service, you pay for shipping to Gemini, we pay for return shipping within the continental United States. Alaska, Hawaii, Puerto Rico, Canada, Bahamas, and the Virgin Islands will be charged for freight.
- E. Please allow 2-3 weeks for return of your product. Under normal circumstances your product will spend no more than 10 working days at Gemini. We are not responsible for shipping times.

gemini®

Empower Your Sound



MPA-K650

Vocero de fiesta de karaoke

Índice

Qué está incluido	9
Características	10
Descripción del producto	11
Precauciones	13
Declaración de cumplimiento de la FCC	13
Legalidad y Seguridad	14
Garantía limitada	15
Devolución / reparación	16

Qué está incluido

Asegúrese de encontrar estos accesorios incluidos con su altavoz ,MPA-K650:

- (1) MPA-K650
- (1) Micrófono con Cable
- (1) Mando a distancia
- (1) Cable de alimentación
- (1) Cable AUX
- (1) Manual
- (1) Correa de transporte



CARACTERÍSTICA

- Woofer de 6.5" con luces de fiesta LED
- Streaming Bluetooth
- Luces de fiesta LED
- USB, tarjeta TF y reproducción de radio FM
- Micrófono con cable incluido
- Entrada auxiliar
- Altavoz Bluetooth con batería recargable
- Cable de carga AC incluido para cargar la batería o jugar

MICRÓFONO

Entrada de micrófono para el micrófono con cable incluido.
 Controles de volumen del micrófono. Microphone Echo para todas tus necesidades de karaoke.

PODER

Control de volumen e interruptor de encendido. Girar para encender

MEDIOS MIXTOS, CONTROL TOTAL

Entrada AUX para conectar cualquier dispositivo externo.
 Entrada USB para reproducir todas tus canciones favoritas.

TÓMELO A LO LARGO DE SUS AVENTURAS

El MPA-K650 presenta una batería de larga duración y un asa de transporte fácil para una máxima portabilidad.

CANTAR JUNTO

Canta con tu música favorita con el micrófono con cable incluido.



VOLUME

Control del volumen. Gire la perilla para encender el altavoz.

MIC VOL

(Volumen del micrófono): se utiliza para ajustar el volumen del micrófono.

MIC ECHO

Se utiliza para ajustar la profundidad del eco del micrófono.

CHARGE

Cuando la línea de alimentación se conecte, el indicador se vuelve rojo y la batería se carga.

FULL

Cuando se apaga la luz roja LED, cuando se enciende la luz verde LED, la batería está cargada.

SD CARD/USB

En la parte superior del dispositivo hay una ranura para tarjetas SD. Para conectar la tarjeta SD, Empuje la tarjeta completamente en la ranura hasta que encaje en su lugar. En la parte inferior del dispositivo hay una ranura para unidad USB donde se puede conectar una memoria USB

AUX

Conecte 1 / 8 " cable para la reproducción en aux

MIC

Se utilizan para conectar la interfaz de enchufe del micrófono de cable.

MODE

Para encender / apagar PLAYER, mantenga presionado MODE. Presione MODE nuevamente para alternar a través de USB, SD o Bluetooth como dispositivo de entrada. La tecla MODE se usa para cambiar el estado de la radio para usar la función de presionar la tecla de radio; Si la frecuencia de recepción necesita ingresar manualmente, presione los números en el control remoto directamente para ingresar la frecuencia de la estación de radio.; Interruptor de luz LED

▶||

Cada pulsación de este botón hace que la pulsación se reproduzca o pausa

LED

Las luces LED se pueden encender y apagar

▶▶|

presione la tecla y la radio leerá la estación de radio guardada y seleccionará la siguiente en orden ascendente

|◀◀

presione la tecla y la radio leerá la estación de radio guardada y seleccionará la anterior en orden descendente

REPEAT

Presione esta tecla para repetir una o todas las canciones

POWER ON/OFF

Use el interruptor de encendido en el panel frontal o el control remoto para encender o apagar.

PANTALLA DE BATERÍA

En la pantalla hay un indicador de duración de la batería con 3 etapas: carga completa, media carga y baja (parpadeando)

CARGADOR DE BATERÍA

Con el cable de alimentación conectado a la red eléctrica, use el interruptor en la parte posterior de la unidad para encender / apagar la carga.

INTRODUCCIÓN

Gracias por comprar nuestro MPA-K650. Confiamos en que la plataforma de productos Gemini no solo le facilitará la vida mediante el uso de los últimos avances tecnológicos en conectividad multiplataforma y reproducción de sonido, sino que elevará el estándar para los productos de DJ y audio profesional. Con el cuidado y mantenimiento adecuados, es probable que su unidad brinde años de servicio confiable e ininterrumpido. Todos los productos Gemini están respaldados por una garantía limitada de 1 año *.

PREPARACIÓN PARA EL PRIMER USO

Asegúrese de encontrar estos accesorios incluidos con el MPA-K650:

- (1) cable de alimentación
- (1) Instrucciones de funcionamiento
- (1) Tarjeta de garantía

PRECAUCIONES

1. Todas las instrucciones de funcionamiento deben leerse antes de usar este equipo.
2. Para reducir el riesgo de descarga eléctrica, no abra la unidad. NO HAY PIEZAS REEMPLAZABLES POR EL USUARIO EN EL INTERIOR. Consulte el servicio técnico a un técnico de servicio calificado de Gemini Sound Products. No intente devolver este equipo a su distribuidor.
3. No exponga esta unidad a la luz solar directa ni a una fuente de calor como un radiador o una estufa.
4. Esta unidad debe limpiarse solo con un paño húmedo. Evite solventes u otros detergentes de limpieza.
5. Al mover este equipo, debe colocarse en su caja y embalaje originales. Esto reducirá el riesgo de daños durante el tránsito.
6. NO EXPONGA ESTA UNIDAD AL AGUA O AL CALOR.
7. NO USE PRODUCTOS DE LIMPIEZA O LUBRICANTES EN LOS CONTROLES O INTERRUPTORES. CONNECTIONS TENGA EN CUENTA QUE ES MUY IMPORTANTE QUE SU AMPLIFICADOR TIENE CLASIFICACIONES DE POTENCIA IGUALES! (Asegúrese de que su equipo esté completamente APAGADO y también baje TODOS los controles de VOLUMEN, NIVEL Y GANANCIA antes de conectar el altavoz). Responsible Party Name: Innovative Concepts & Designs

Company address:

458 Florida Grove Road Perth Amboy, NJ, 08861 USA FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. The operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and then on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to a different outlet so that the equipment and receiver are on different branch circuits.

Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AE6G-MPAK650

LEGALIDAD Y SEGURIDAD

El dispositivo no está diseñado para ser utilizado por personas (incluidos niños) con capacidad física, sensorial o mental reducida. Las personas que no hayan leído el manual, a menos que hayan recibido una

explicación de alguien responsable de su seguridad, no deben usar esta unidad. Los niños deben ser monitoreados para asegurarse de que no jueguen con el dispositivo. El dispositivo siempre debe ser

fácilmente accesible. El dispositivo no debe exponerse al agua. No se colocarán objetos llenos de líquidos, como jarrones, sobre el dispositivo. Deje siempre una distancia mínima de 10 cm alrededor de la unidad para garantizar suficiente

ventilación. Las fuentes de llamas abiertas, como las velas, no se deben colocar encima del dispositivo.

El dispositivo está diseñado para usarse solo en un clima templado. A todo volumen, la escucha prolongada puede dañar su audición y causar sordera temporal o permanente, zumbido auditivo, tinnitus o hiperacusia. No se recomienda escuchar a un volumen alto. Una hora por día tampoco es recomendable.

Peligro de explosión si la batería se reemplaza incorrectamente o no se reemplaza por el mismo tipo o equivalente. La batería no debe exponerse a calor excesivo como la luz solar o el fuego. No se deben mezclar diferentes tipos de baterías, o baterías nuevas y usadas. La batería debe instalarse de acuerdo con su polaridad. Si la batería está desgastada, debe retirarse del producto. La batería debe desecharse de manera segura. Utilice siempre contenedores de recolección para proteger el medio ambiente. La batería solo puede ser reemplazada por el fabricante de este producto, el departamento de ventas o una persona calificada. Apague el dispositivo donde el uso del dispositivo no esté permitido o donde exista el riesgo de causar interferencia o peligro, por ejemplo: en un avión o cerca de equipos médicos,

combustible, productos químicos o sitios de explosión. Verifique las leyes y regulaciones actuales con respecto al uso de este dispositivo en las áreas donde conduce. No manipule el dispositivo mientras conduce. Concéntrese completamente en conducir. Todos los dispositivos inalámbricos son susceptibles a interferencias que pueden afectar su rendimiento. Todos nuestros dispositivos cumplen con las normas y regulaciones internacionales / nacionales, y nuestro objetivo es limitar la exposición del usuario a los campos electromagnéticos. Estas normas y reglamentos fueron adoptados después de la finalización de una extensa investigación científica. Esta investigación no estableció ningún vínculo entre el uso de los auriculares móviles y cualquier efecto adverso sobre la salud si el dispositivo se usa de acuerdo con las prácticas estándar. Solo personas calificadas están autorizadas para instalar o reparar este producto.

Utilice solo baterías, cargadores y otros accesorios que sean compatibles con este

equipo. No conecte productos incompatibles. Este equipo no es resistente al agua. Manténlo seco.

Mantenga su dispositivo en un lugar seguro, fuera del alcance de los niños pequeños. El dispositivo contiene piezas pequeñas que pueden presentar un peligro de asfixia para los niños.

GARANTÍA

- A. Gemini garantiza que sus productos están libres de defectos de materiales y mano de obra durante un (1) año a partir de la fecha de compra original. Excepciones: los ensamblajes láser de los reproductores de CD, baterías, cartuchos y crossfaders están cubiertos durante 90 días.
- B. Esta garantía limitada no cubre daños o fallas causados por abuso, mal uso, uso anormal, instalación defectuosa, mantenimiento inadecuado o cualquier reparación que no sea la proporcionada por un Centro de Servicio Gemini autorizado.
- C. No hay obligaciones de responsabilidad por parte de Gemini por daños emergentes que surjan de o en conexión con el uso o desempeño del producto u otros daños indirectos con respecto a la pérdida de propiedad, ingresos, ganancias o costos de remoción. , instalación o reinstalación. Todas las garantías implícitas para Gemini, incluidas las garantías implícitas de idoneidad, tienen una duración limitada a un (1) año a partir de la fecha original de compra, a menos que las leyes locales exijan lo contrario.

DEVOLUCIÓN / REPARACIÓN

- R. En los Estados Unidos Llame a nuestros útiles representantes de servicio al cliente al (732) 346-0061, y con gusto le proporcionarán un número de autorización de devolución (RA #) y la dirección del centro de servicio autorizado más cercano a usted.
- B. Después de recibir un RA #, incluya una copia del recibo de venta original, con el producto defectuoso y una descripción del defecto. Envíe por flete asegurado a: Gemini y utilice la dirección proporcionada por su representante de servicio al cliente. Su número de RA debe estar escrito en el exterior del paquete, o el procesamiento se retrasará indefinidamente.
- C. Gemini pagará el servicio cubierto por la garantía y se lo devolverá. En el caso de productos sin garantía, Gemini reparará su unidad después de recibir el pago. Los gastos de reparación no incluyen el flete de devolución. Los gastos de transporte se añadirán a los gastos de reparación.
- D. En el servicio de garantía, usted paga el envío a Gemini, nosotros pagamos el envío de devolución dentro de los Estados Unidos continentales. Alaska, Hawái, Puerto Rico, Canadá, Bahamas y las Islas Vírgenes se cobrarán por el flete.
- E. Espere de 2 a 3 semanas para la devolución de su producto. En circunstancias normales, su producto no pasará más de 10 días hábiles en Gemini. No somos responsables de los tiempos de envío.

MPA-K650**Portable Karaoke Party Speaker****DECLARATION OF CONFORMITY****Safety And EMC Compliance Specifications**

The purpose of the statement described above is consistent with applicable union harmonization legislation:

RED 2014/53/EU

ETSI EN 300 328 V2.1.1(2016-11)

ETSI EN 301 489-1 V2.1.1(2017-02)

ETSI EN 301 489-17 V3.1.1(2017-02)

EN 62479:2010

EN 60950-1:2006+A11:

2009+A1:2010+A12:2011+A2:2013

EN 60065:2014

The RoHSDirective 2011/65/EU

IEC 62321-3-1:2013

IEC 62321-5:2013

IEC 62321-4:2013

IEC 62321-6:2015

IEC 62321-7-1:2015

IEC 62321:2008 ANNEX C

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules.

The operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and then on, the user is encouraged to try to correct the interference by one or more of the following

Measures:

“ Reorient or relocate the receiving antenna.

“ Increase the separation between the equipment and receiver.

“ Connect the equipment to a different outlet so that the equipment and receiver are on different branch circuits.

“ Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AE6G-MPAK650