

USER GUIDE

HOW TO OPEN/CLOSE:



1 To open the chair, hold the top of the backrest of the chair and gently pull away seat from the back of the seat until the frame is open and the chair securely clicked in place.


2 To close, hold the top of the backrest of the chair and gently pull the front of the chair inwards. The chair will then fold into the closed position.

HOW TO EXTEND FOOTREST:

3 Pull the footrest from under the seat and rotate until the footrest is in position.



HOW TO RECLINE:



4 Gently lift the armrests upwards. Lean back slowly, allowing the chair to recline until you find your preferred position. Before settling into this position, double-check that the armrests are securely locked in place.

Enjoy relaxing in your Ergo+ chair!

USER GUIDE CONTINUED

✦✦ CARE INSTRUCTIONS:



**Spot clean
with water only**



Air Dry



**Do not use bleach
or harmful chemicals**



WARNING:

1. This chair holds a maximum of **300 lbs.** Exceeding this limit will damage the chair and/or may cause personal injury
2. Use chair on level ground
3. To avoid injuries to fingers, use care when folding the chair

WARRANTY

Caravan® Global warrants that each part of this product will be free from defects in material and workmanship for sixty (60) day period from date of purchase.

This warranty is void :

- If product is used under other than normal use and maintenance conditions.
- If the product is modified or altered.
- If product is subject to abuse or neglect.
- If product damage is accidental or deliberate or caused by rain, wind or other forces of nature.
- If product use does not conform to product instructions.
- If product is repaired by someone other than Caravan® Global or its authorized representative.

The sole obligation of Caravan® Global under this warranty or any other legal obligation, with respect to the product, is repair or replacement, by Caravan® Global or its authorized representative, of the missing or defective parts causing malfunction with new parts after review and examination by Caravan® Global.

Under no circumstances will the retail customer, user, authorized representative or other person be entitled to any direct, special, indirect, consequential or exemplary damages for breach of contract or otherwise. Under no circumstances will any person be entitled to a sum greater than purchase price of the malfunctioning part.

No Caravan® Global authorized representative or person other than an officer of Caravan® Global may extend or modify this warranty. There are no other warranties from either Caravan® Global or its representatives which extend the face of this warranty. All other warranties, expressed or implied, including the warranties of merchantability, fitness for a particular purpose and fitness for use are excluded.

Please contact Caravan® Global for specific shipping instructions before returning any part. All shipping costs must be pre-paid. Caravan® Global will not be responsible for any products damaged in transit.