


# my first Watchie-Talkies



## HOW TO OPERATE

1. Open BATTERY COMPARTMENT (Fig. 5) Loading 3 1.5V "AAA" batteries. Replace door firmly.
2. Turn the "ON/OFF" switch (Fig. 2) to "ON".
3. Press the "PUSH-TO-TALK" button (Fig. 3) for transmitting, and speak in a normal voice level into the speaker/microphone grille (Fig. 4).
4. Release the "PUSH-TO-TALK" button (Fig. 3) for receiving.
5. Best transmission and reception are obtained when the FLEXIBLE ANTENNA (Fig. 1) is held in vertical position.

1. When the sound becomes weak, it is time to change the battery.
2. After use always turn the ON/OFF CONTROL switch to the "OFF" position.
3. Keep your set in a dry place.
4. Take out the batteries when not in use.
5. Do not use rechargeable batteries.



Manufactured for  
Odyssey Marketing, LLC  
Miami, FL 33179  
Customer Service: 305-933-4480  
Hours of operation:  
M-F 10:00am-4:00pm EST  
Email: Care@OdysseyToys.com  
60-Day Limited Warranty.  
More info here: Odysseytoys.com  
Product and colors may vary.

MADE IN CHINA  
Model No. ODY-1209RG

CAUTION

**& WARNING**  
CHOKING HAZARD - Small parts,  
not for children under 3 years.



odysseytoys.com