

DEAR CUSTOMER,

Congratulations on your purchase of a FLIPO ® product. Our products will help to enhance the beauty of your home and provide many years of enjoyment. FLIPO ® offers a wide variety of unique lighting products of the highest quality. To ensure the maximum performance of your flameless candle, please read and save these instructions.

ALEXANDRIA HURRICANE

BATTERY INSTALLATION

Remove the battery compartment lid; insert 2 C batteries as indicated on the candle bottom/battery compartment; for best performance, we suggest using only alkaline batteries. Replace and close the battery compartment lid. It is advisable to place the candle on a soft surface to support the candle when installing or changing batteries.

AUTOMATIC TIMER

Your candle has three activation positions – OFF, 4 Hour and 8 Hour. When in the OFF position your candle will remain inactive. When the timer position is selected in either the 4 Hour or 8 Hour position at any given time of the day, the flickering light will turn on and then automatically turn off after the selected time duration. The following day, if the switch setting has not been modified, the flickering light will automatically turn on at the same time and will automatically turn off after either 4 or 8 hours depending on the interval selected. To change starting time, cycle the switch to OFF and back to either 4 Hour or 8 Hour at the desired time.

HURRICANE SET UP/CHOOSING A LOCATION

Your Alexandria should be always be placed on a flat and stable surface. Place the glass shade in the center of the stand. After activating your candle per above instruction, place it in the center of the shade. The flameless candle and hurricane should not be exposed to extreme weather such as heat, cold, rain or snow and are intended for indoor use only. Your flickering candle is made of wax and should not be placed near a heat source such as a radiator, stove, fireplace, etc. – the extreme heat may melt the candle's wax.

CANDLE LIGHT MAINTENANCE

To clean the hurricane shade remove it from the base and wipe with a clean damp non-abrasive cloth. The wooden base can be cleaned in the same way or with a dust cloth. **NEVER** clean with detergent, bleach or other harsh chemicals; doing so will damage the surfaces of these items.

CAUTION

1. This product is a Flameless Candle, to avoid fire hazard, do not light wick with fire.
2. The stand and shade are designed for use with the flameless candle included in your Hurricane Lamp. They are not intended for use with real candles and should **NEVER** be used in that way.
- 3 Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
4. Do not mix old and new batteries.
5. For best results, use alkaline batteries.
6. Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
7. Do not dispose of batteries in fire.
8. Batteries should be recycled or disposed of as per manufacturer's recommendations.
9. **WARNING! THIS ITEM IS FOR INDOOR USE ONLY!**

BATTERIES NOT INCLUDED

CUSTOMER SERVICE

For questions or support, please call (815) 223-9942 or e-mail info@flipo.com.