DEAR CUSTOMER,

Congratulations on your purchase of a FLIPO ® product. Our products will help to enhance the beauty of your home and provide many years of enjoyment. FLIPO ® offers a wide variety of unique lighting products of the highest quality. To ensure the maximum performance of your flameless candle, please read and save these instructions.

SEDONA HURRICANE

BATTERY INSTALLATION

Access the battery compartment by twisting the plastic base in a counter clockwise manner. Insert 2 AA batteries into the compartment; the batteries should be installed with the positive (+) terminal inserted first. For best performance, we suggest using only alkaline batteries. Replace and close the battery compartment by pushing the bayonet closure down and twisting in a clockwise manner; you should feel the base lock in place. It is advisable to place the candle on a soft surface to support it when installing or changing batteries.

AUTOMATIC TIMER

Your candle has a push button located on its base. The button has two activation positions — OFF and a 6 Hour timer. When in the OFF position your candle will remain inactive. When the button is depressed, the 6 Hour timer is selected and the flickering light will turn on and then automatically turn off after 6 hours. The following day, if the switch setting has not been modified, the flickering light will automatically turn on at the same time and will automatically turn off after 6 hours. To turn off, press the button again.

If you want your taper to illuminate at a different time, choose the time you want it to activate and turn the taper off. Wait at least 60 seconds, and then reactivate it by depressing the button again.

HURRICANE SET UP/CHOOSING A LOCATION

Insert the suspended metal frame into the glass hurricane; its arm should rest on top of the hurricane's lip. After activating your candle per above instruction, place it in the frame's holder. The Sedona Hurricane should be placed on a flat surface. The flameless candle and hurricane should not be exposed to extreme weather such as heat, cold, rain or snow and are intended for indoor use only. Your flickering candle is made of wax and should not be placed near a heat source such as a radiator, stove, fireplace, etc. – the extreme heat may melt the candle's wax.

CANDLE LIGHT MAINTENANCE

To clean the hurricane, wipe the glass hurricane and metal frame with a clean damp non-abrasive cloth. <u>NEVER</u> clean with detergent, bleach or other harsh chemicals; doing so will damage the surfaces of these items.

CAUTION

- 1. This product is a Flameless Candle, to avoid fire hazard, do not light wick with fire.
- 2. The glass hurricane and metal frame are intended for use with the flameless candle included with your product. They are not intended for use with real candles and should <u>NEVER</u> be used in that way.
- 3 Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
- 4. Do not mix old and new batteries.
- 5. For best results, use alkaline batteries.
- 6. Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- 7. Do not dispose of batteries in fire.
- 8. Batteries should be recycled or disposed of as per manufacturer's recommendations.
- 9. WARNING! THIS ITEM IS FOR INDOOR USE ONLY!

BATTERIES NOT INCLUDED