

WIRELESS SENSOR LED WINDOW CANDLES (SET OF 6)

Item No. 210334

User Guide

Thank you for purchasing the Wireless Sensor LED Window Candles [Set of 6]. Please read this manual thoroughly before operating this device.

INSTRUCTIONS

NOTE: *Batteries need to be installed in the base.*

1. Open Battery Compartment:

- Turn the candle over and remove the battery compartment cover.

2. Insert Batteries:

- Insert 2 AA batteries, ensuring the positive ends [+] are pointing in the correct direction.

3. Secure Battery Compartment:

- Snap the cover back into place.

4. Select Setting:

- Choose the desired setting: Off, On, or Auto Sensor [automatically shuts off the candle during daylight hours].

5. Position the Candle:

- Place the candle with the photocell facing the light source.

WARRANTY AND CUSTOMER SERVICE

This item from SharperImage.com includes a 1-year limited replacement warranty. If you have any questions not covered in this guide, please call our Customer Service department at 1 (877) 210-3449. Customer Service agents are available Monday through Friday, 9:00 a.m. to 6:00 p.m. ET.

SHARPER IMAGE®

The SHARPER IMAGE® name and logo are registered trademarks.
©Sharper Image. All Rights Reserved.