




White = RiddiaPress is turned on
Blue = RiddiaPress is charging
LED turns off when fully charged

riddiapress

HOW TO USE

Heat and wait.

Allow 1 minute for RiddiaPress to heat up.
RiddiaPress shuts off if idle for too long.

Press firmly.

Hold RiddiaPress firmly against garment
and move slowly along each crease for
at least 1 minute. Repeat if necessary.


Charge and use daily.

One full charge of RiddiaPress gives you
one wrinkle-free garment.

- ⚠ Remove plastic film before use.
- ⚡ Switch off before charging.
- 🔌 Do not touch metal plate when on.

FCC Compliance - SKU: MGIP0031BK

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Responsible party can be reached at team@magisindustries.org (see Importer).



- ⌚ Move RiddiaPress slowly along a crease for at least 1 minute.

- 👕 Use with garments having one of these laundry tag symbols.