


User's Manual

ST-HALO

HOME SPEAKER & CHARGING TABLE



Thank you for purchasing ST-HALO Home Speaker & Charging Table, in order to make the best use of this product and to use it safely, please read the manual carefully before use and keep it for future reference.

Warnings



The maximum load weight of this product is 25 lbs. Do NOT put any more weight than the maximum load as damage to the unit and top glass can occur and void any warranty.




Please do NOT sit on table. It is not safe and it is not designed to be a seat.




Please use ONLY the original AC adapter for powering the table. Use of other adapters may cause the table to not function properly and in extreme cases can cause the adapter to burn out or cause other damage and/or injury.

What is in the box




x1 Sound Table



x1 AC Adapter



x1 Instruction Manual



x1 Wood Shelf



x3 Poles




x4 Wood Legs


Assembly

1. On a flat, soft surface, carefully remove all the components. Place table with wood top side down on soft surface to expose bottom of the table with fixed holes.
2. Take one of the legs and insert into one of the fixed holes on the table. Turn clockwise to tighten.
3. Repeat for each of the remaining legs. Make sure all the legs are tightened.
4. Carefully lift the table and turn it over, setting it on the legs.
5. Take one the poles and insert into one of the fixed holes on the top of the table. Turn clockwise to tighten.
6. Repeat for each of the remaining poles. Make sure all the poles are tightened.
7. Take the wood shelf and match the holes to poles. Push down to insert poles. Carefully lift the table to make sure all the poles are fully assembled and the shelf remains attached.


Step 1




Step 2




Step 3




Step 4




Step 5



Step 6



Step 7



Specifications

Built-in Speaker System (2.0 CH)

Drive units: Mid-Range: 3" 4Ω 15W x 1 + Tweeter: ϕ 36mm 8Ω 10W x 1

RMS: 24W (12W x 2), Max Output: 30W (15W x 2), Max Power: 50W (15W x 2 + 10W x 2)

Lighted Drawer: White LED

Bluetooth Frequency Range: 2.402-2.480GHz

Frequency Range: 90Hz-18KHz

S/N: $\geq$ 75dB

Separation Ratio: $\geq$ 55dB

Bluetooth Version: 5.0

Bluetooth Transmit Distance: 10m/33ft

Operating Voltage: DC 16V $\equiv$ 3A

Dual Charging Port: USB & Type-C (20W Max)

Wireless Charging: 10W (Max)

Waterproof Standard: IPX3

Rechargeable Battery: 11.1V 2200mAh (3PCS 18650 3.7V/2200mAh connection in series)




Power Supply: Input: AC 100-240~ 50/60Hz, Output: DC 16V $\equiv$ 3A

Material: MDF with tempered glass, 100% cationic polyester mesh, PP base

Diameter: ϕ 408mm Height: 695mm

Parts and Functions

1. Power ON/OFF/TWS
2. Volume Down -
3. Play/Pause/Bluetooth Connection
4. Volume Up +
5. EQ (POP/ROCK/MOVIE)
6. Wireless Charger
7. USB Charging Port
8. Type-C Charging Port
9. DC Input Connection



Power ON / OFF

To Power ON Sound Table for the first time:

1. Connect the AC adapter to the DC input on the side of the table. Please make sure you use the original AC adapter that came with the Sound Table.
2. Install the power plug into the AC adapter and plug into an outlet.
3. Long press the TWS button, the Sound Table will say “Power On”, and enter Bluetooth mode as the default model and say “Bluetooth, waiting for connection.”
4. Pair smart phone or other Bluetooth device at this time.

NOTE: If no Bluetooth connection, Line-in signal or disconnect is made, the speaker will power off automatically and say, “Power Off.” Long press the POWER/TWS button on the table to wake up the Sound Table.


To Power On Sound Table:

1. Long press the POWER/TWS button.
2. You will hear “Power On”, and it will enter Bluetooth mode.
3. If a device has not previously been paired, Sound Table enters Bluetooth mode, you will hear “Bluetooth, waiting for connection.”
4. If a device has previously been paired to the Sound, you will hear “Bluetooth connected.” If pairing a new device, do so now.

To Power OFF Sound Table

1. Long press the POWER/TWS button.
2. You will hear “Power Off” and Sound Table will power off.

Bluetooth Connection and Play (LED indicator: the first LED)



1. When the speaker is in Bluetooth model, it will automatically enter pairing mode. The blue LED light will flash quickly. Note: Bluetooth device name will appear as “ST-HALO.”
2. The speaker will pair with a smart phone via Bluetooth. Once connected the speaker will say “Bluetooth is connected.” The blue LED will remain on. If connection failed, the blue LED light will flash rap and you will need to retry pairing.
3. When playing music after connecting, the speaker will pause when the  is short pressed. It will play once it is short pressed again.
4. When the speaker is connected, the speaker will switch off the connection of the paired device if the  is long pressed. Once pressed the speaker will announce “Bluetooth disconnected, waiting for connection.” At this time, another device can connect to the Sound Table. In the same way, the Bluetooth connection will switch on if the  is long pressed, and the speaker will announce “Bluetooth, waiting for connection.”

EQ Switch (LED indicator: the second LED)



EQ Indicators

NO ILLUMINATION: Normal Mode

RED: Pop Mode

GREEN: Rock Mode

YELLOW: Movie Mode

When the speaker is powered on, it will enter normal mode by default, the LED indicator will not be illuminated. The speaker will enter “POP” mode with a short press to the  button and the LED will turn red. With another short press to the  button the speaker will enter “ROCK” mode and the LED will turn green. The speaker will enter “MOVIE” mode with another short press to the  button and the LED will be yellow. To return to normal mode, short press the  button once more. The Sound Table will remain in the same EQ mode if power is turned off (Standby mode). However, if the AC adapter is unplugged and then reinserted, the EQ will return to default normal mode.

Voice Reminder:

1. POWER ON: Connect the power supply (voice prompt when the speaker turns on).
2. BLUETOOTH: Bluetooth mode.
3. POWER OFF: Shut off the power supply (voice prompt when the speaker turns off).
4. WAITING FOR CONNECTION: Pairing (enter Bluetooth mode, and back to Bluetooth mode).
5. BLUETOOTH IS CONNECTED: Pairing is successful, in Bluetooth mode.
6. BLUETOOTH DISCONNECTED, Wait for Connection: Pairing has been disconnected. (Long press  to disconnect Bluetooth).
7. MAXIMUM VOLUME: Volume is at the maximum level. Maximum level is 31.
8. BATTERY-LOW: The built-in battery needs to be charged.

Volume Control

1. Press  button to increase the volume. The LED will flash white. Speaker will default to level 10 when turned on. Maximum volume is 31. Speaker will announce “Maximum Volume.”
2. Press  button to decrease volume. The LED will flash white.

The Sound Table can keep the previous volume level in memory if power is turned off (Standby mode). However, if the AC adapter is unplugged and then reinserted, the EQ will return to default level 10.

Automatic Power Off (Standby mode)

1. After powering on the speaker, if no Bluetooth connection or no Line In signal has been established, the speaker will power off automatically and say “Power Off.”
2. Long press the POWER/TWS button on the top of the table to wake up the Sound Table.

USB & Type-C Charging

When the speaker is powered on, the Dual Charging Ports (USB & TYPE-C) can charge mobile devices (Dual Charging output is 20W Max). NOTE: The Dual Charging Ports can charge mobile devices even when the speaker is powered off, as long as the speaker is plugged into the power outlet or switch to battery button on the side of the table.

Wireless Charging

If you have a device with wireless charging capability, it can be charged by placing the device on one of the wireless charging symbols located on the top of the table. Make sure to center the device on the charging symbol. You can remove your device at any time to end the charging process. The wireless chargers can charge mobile devices even when the speaker is powered off as long as the speaker is plugged into the power outlet.

Wireless charging symbol will be illuminated when not charging a device. When charging a device they will not be illuminated.

TWS Function (LED indicator: the third LED)



TWS feature allows you to link two Sound Tables together. The first table will be the master connected to the Bluetooth device and operate all of the controls, including power on/off. The second table is a linked speaker to the master.

1. Turn on both Sound Tables.

2. Double click the  button. The speakers will enter pairing mode. The LED will flash orange rapidly. After the pairing is complete, the LED of the master speaker will remain solid and the linked speaker will flash slowly.

3. To disconnect the pairing, short press the  button once to switch off the TWS pairing.
4. Both speakers can be turn off via TWS pairing mode.



5. Long press the ^{TWS} button will wake up the Sound Table in standby mode. Double click the ^{TWS} button, the speakers will enter TWS pairing mode.



APP INSTALLTION

Please scan the QR code below to download the APP:



Note: The APP for Android devices uses Bluetooth Low Energy (BLE) communication to the Sound Table, requiring access the location information. Confirm all prompts for location access when installing the App from Google Play.

1. Connect Device to Sound Table

Go to your Device's Bluetooth menu in your settings.

Search for nearby Bluetooth devices.

Tap "ST-HALO" to connect to the Sound Table. You are now able to stream audio to the Sound Table.

2. Connect APP to Sound Table

Once paired to your device, the APP will automatically connect to the Sound Table.