


MODEL:MXJD288



1 IMPORTANT

- Power supply must be DC12V.
- This is a high-volume low-pressure pump. It is intended to inflate/deflate items, such as inflatable boat mattress, etc. This pump is not designed for continuous use. Extended operation over 12 minutes can overheat and damage the pump.
- Do not obstruct the inflation/deflation port and keep them ventilated all the time.
- For fast inflation and shorten the motor's working time, always use the suitable adapter according to the size of valve of inflatable item.

2 WARNING


- Pump Use DC12V Only.
- To Reduce the Risk of Electric Shock or Injury, Use DC12V Only
- This appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.
- Any other servicing should be performed by an authorized service representative.
The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for safety.
- Children should be supervised to ensure that they do not play with the appliance.
Carefully following the instructions on inflatable item when inflating. Never exceed recommended pressure, otherwise, serious injury might be caused by the bursting item.
- Never allow water and liquid be touched by pump or plug when pump is working.
- Keep the air pump out of the reach of children and pull out the plug when the pump is not working.

MODEL:MXJD288

- Never look inside or point the inflation/deflation port toward your Eyes when the pump is working.
- Never attempt to put hand or fingers into the inflation/deflation Port at any time.
- Do not keep/use the pump and plug in wet condition.
- Never allow sand, small rocks, etc, to be sucked into inflation/deflation Port when using the pump.
- Never leave pump unattended while pump is in use.
- The supply cord cannot be replaced. If the cord is damaged, the appliance Should be scrapped.

3 TO INFLATE ITEMS

- Connect plug to 12V volt DC socket.
- Join adapter to inflation port, then hold Pump against valve of inflatable item and Switch on for inflation/switch off for stop. (the symbol “-” on the switch means “ON”, “0” means “OFF”)
- The valve of inflatable item should not be obstructed; Otherwise, it could overheat and damage the pump
- Never use the deflation vent when inflating the item.
- On large items like inflatable boat, king-size air mattress, the Pump should fit directly to the valve of inflatable item for fast Inflation. use the appropriate adapter for small valve, such as Single-size air mattress, etc.



4 TO DEFLATE ITEMS

- Open the valve of inflatable item
- Join adapter to deflation port, then insert It in the valve and switch on for Deflation/switch off for stop. (the symbol “-” on the switch means “ON”, “0” means “OFF”)
- The valve of inflatable item should not be Obstructed; otherwise, it could overheat and Damage the pump.
- For small valve of inflatable item, it may be pinched your Fingers to open the flapper of valve and allow the air to escape.
- For quickly inflating the item with screw valve, unscrew the Safe bolt, then inflate directly with the pump. When finishing, Screw the safe bolt, then remove the top of the safe bolt for Fully inflating the item For deflation, unscrew the safe bolt To deflate directly.

