



Check out all of our other cool products by going to www.BandDGroup.com

MADE IN CHINA



For Customer Service or if you need to service your product please email:

Service@BandDGroup.com. Please note the product model number, your name and phone number in the email message: AirCandy® Inflatable Ottoman

Contents:

- One Inflatable Ottoman
- Instruction Manual
- Patch Kit

Legal

B&D Innovations and AirCandy are trademarks of B&D Group, LLC. Actual product may differ slightly from photograph.

Care & Maintenance

1. Inspect your ottoman prior to each use.
2. Keep your ottoman away from any sharp objects. Large cuts or snags may not be repairable and will not be covered by your warranty.
3. When not in use, store your ottoman in a clean, dry place out of extreme temperatures. Product must be at room temperature prior to inflating.
4. In case of incidental damage to your ottoman, a repair kit has been included. Please follow repair instructions carefully.
5. If your ottoman requires cleaning you may use soap and water with a wash cloth. Dry the ottoman before you consider storage.

Inflation, Deflation & Storage

NOTE: Product must be at room temperature prior to inflating or it may cause air leaks. Do not over inflate the ottoman as it may damage or burst under too much pressure.

1. Open the air nozzle to start the releasing of the air.
2. Pinching the nozzle can help to increase the volume of air being released. Do not aggressively force the air out of the ottoman as this may damage it.
3. For the fastest results use an electric or battery powered air pump in the reverse position to have the air automatically released in just a few minutes. A battery pump can be found at a retail store near you or at www.ThePoolCandy.com
4. After the ottoman has been completely deflated you may fold it flat for easy storage back in the box or in a drawer. Never store your ottoman when wet, be sure to completely dry it before putting it away.
5. Store your Inflatable Ottoman in a clean dry place at room temperature (above 50° F/ 10° C). Storing your Ottoman under 50°F (10°C) and over 100°F (38°C) may affect its performance and will not be covered under warranty.

www.BandDGroup.com

WARNING: Adult supervision required for inflation, deflation and maintenance. Follow all safety instructions to avoid serious injury.

- For household/residential use only.
- This ottoman is not intended for infants or persons with limited mobility. They may roll off of the ottoman and become entrapped between the ottoman and a wall.
- Remove all sharp objects from area where the ottoman will be set up and used as the ottoman could puncture.
- Do not step or jump on the ottoman at any time.
- Place the ottoman in a safe area before use, making sure that there are no sharp edges, steps, drops or breakable items nearby. Use on flat surfaces only as the ottoman may tip over on uneven surfaces.
- Do not use this ottoman on abrasive surfaces or near pointed/sharp items. Protruding objects may puncture the ottoman.
- This ottoman is made of plastic and therefore may melt or burn if it comes in contact with any flame, spark or heat source. Do not place it near or against heaters, open flame or other hot objects.
- Be sure to turn off the ottoman lights when not in use.

CAUTION – DO NOT PLACE ON ROUGH GROUND OR NEAR SHARP OBJECTS AS THIS MAY CAUSE DAMAGE TO THE UNIT

MODIFICATIONS NOT APPROVED BY B&D GROUP, LLC. VOIDS WARRANTY.

LIMITED 90-DAY WARRANTY

B&D Group, LLC, warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 90 days from the date of purchase. If any such defect is discovered within the warranty period, B&D Group, LLC. will repair or replace the unit free of charge upon receipt of the unit, shipping postage prepaid and insured to the factory address received from Customer Service. The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. Removal of any panels voids all warranties. This warranty does not cover cost of repairs made or attempted outside the factory. Any applicable implied warranties, including warranties of merchantability and fitness are hereby limited to 90 days from the date of purchase. Expressed or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply. The only authorized service center in the United States would be communicated from Customer Service. Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter detailing the complaint or issue, along with your daytime telephone number, name and address inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to Service@BandDGroup.com, specifying the model number and the problem.

PLEASE DO NOT SEND YOUR UNIT WITHOUT RECEIVING AN ESTIMATE FOR SERVICING. WE CANNOT STORE YOUR UNIT.

AIRCANDY OTTOMAN



INSTRUCTION MANUAL

GETTING TO KNOW YOUR AIRCANDY® INFLATABLE OTTOMAN

Congratulations on the purchase of your AirCandy Inflatable Ottoman! It is comfortable like a bean bag yet strong enough to easily hold up to a 200 LB person. Manufactured with heavy duty PVC material, your ottoman is ideal for use both indoors and outdoors, and it is even waterproof if you want to take it in the pool.

It's the perfect ottoman for dorm rooms, and camping trips, and just about anywhere you need an instant comfy seat. It inflates in minutes and folds easily for storage in a drawer.

Preparation of your inflatable ottoman requires no tools. However, we recommend using a pump for easiest set up.

There are two nozzles on the bottom of the ottoman that need to be inflated. The outer nozzle controls the outer area of the ottoman and the inner nozzle controls the seat.

Please inflate for your own comfortability as it does vary from person to person. A full inflation will make the ottoman very firm and a slightly lower inflation will provide a bean bag type effect allowing you to sink into the ottoman just a little. Please use caution to not over inflate the ottoman.

GETTING TO KNOW YOUR AIRCANDY® INFLATABLE OTTOMAN



Inflation nozzles are found on the bottom of the Ottoman.


USING THE REMOTE FOR YOUR ILLUMINATED INFLATABLE CHAIR

The remote control handles the functions of the multi-colored LED light disc. When using the remote for the first time, please pull out the battery protection tab to activate the battery.

Please refer to the diagram on the next page for an explanation of the buttons.

- A. Left – Brightness Up
Right – Brightness Down
- B. Left – Power Off
Right – Power On
- C. With the combination of 12 colors and 10 different brightness levels you have over 120 color option combinations to choose from throughout the various special light modes.
 - Flash – Want your chair to stand out? Show it off with 'Flash'
 - Strobe – If you're throwing a party, you can let the Chair help set the mood.
 - Fade – If you are looking to mellow out and relax, 'Fade' is meant for you.
 - Smooth – For the times you want to chill while colors float around the room. 'Smooth' is sure to be what you are looking for.
- D. Color Shades – choose from the various colors until you find the one that is just right for you. For best lighting results, use the illuminated chair in a dark room or at night when outdoors.

USING THE REMOTE FOR YOUR ILLUMINATED INFLATABLE OTTOMAN



NOTE – REMOTE CONTROL IS NOT WATERPROOF.
Remote control requires 1 x CR2025 battery, included.