

DANYCO LLC
Adjustable Hat Shaper
Model No: HS15



Instructional Guide

Patents Pending

Safety Precautions

We want to ensure your safety while using Hat Shaper. Please take note of the following safety precautions:

1. **Indoor Use Only:** For indoor use only. Do not use outdoors where direct sunlight or moisture may be present.
2. **Keep away from water:** Do not attempt to dry a dripping wet hat. Do not use in or around water as it may cause an electrical shock.
3. **Heat Exposure:** Do not expose Hat Shaper to direct heat sources such as flames or hot surfaces. Excessive heat can cause deformation or damage to the material.
4. **Supervision:** If children are present, ensure they are supervised when using or handling Hat Shaper to prevent accidents or misuse.
5. **Storage:** Unplug Hat Shaper when not in use. Store Hat Shaper in a safe location away from children and pets.
6. **Manufacturer's Recommendations:** Do not use Hat Shaper other than for its intended use. Follow all instructions and recommendations provided by the manufacturer for safe and effective usage of Hat Shaper.

Instructions for Cleaning a Hat

These are suggestions and general guidelines for cleaning a hat. It is your responsibility to ensure your hat is cleaned properly. Hat Shaper is only designed to naturally dry (no heat) your hat after it has been cleaned. Cleaning supplies are not included.

1. **Assess the Material:** Before cleaning your hat, determine the material it's made of. Different materials require different cleaning methods to avoid damage.
2. **Spot Cleaning:** If there are small stains or spots on your hat, spot clean them using a mild detergent or stain remover. Dab the affected area gently with a soft cloth or sponge, then blot with a clean, damp cloth to remove the cleaning solution.
3. **Hand Washing:** For hats made of durable materials like cotton or wool, hand washing is often the best option. Fill a basin or sink with lukewarm water and a small amount of mild detergent. Gently swirl hat in the water, paying extra attention to soiled areas. Rinse thoroughly with cool water until all soap residue is removed.
4. **Machine Washing (if applicable):** Some hats, particularly those made of sturdy materials like cotton or polyester, may be machine washable. Use a gentle cycle and cold water to avoid shrinking or damaging hat's shape. Place hat in a mesh laundry bag to protect it during the wash cycle.
5. **Magic Eraser:** To get rid of sweat stains try using water and a magic eraser. This works amazingly well and is very gentle on fabrics.
6. **Brushing (if applicable):** Use a soft-bristled brush to remove dirt and debris. Gently brush in the direction of the material's grain to avoid damaging the fibers.
7. **Additional Tips:** Always read and follow any care instructions provided by the manufacturer. Test any cleaning products or methods on a small, inconspicuous area of hat before proceeding with the entire cleaning process.

Instructions for Starching a Hat

Starching a hat can help maintain its shape and give it a crisp, polished appearance. These are suggestions and general guidelines for starching a hat. It is your responsibility to ensure your hat is starched properly. Hat Shaper is only designed to naturally dry (no heat) your hat after it has been cleaned and starched. Starch supplies are not included.



1. **Prepare Your Materials:** Heavy Spray Starch in a can (recommended), or mix your own liquid starch from cornstarch or potato starch
2. **Dilute the Starch (if using liquid starch):** Follow the instructions on the liquid starch packaging to dilute it with water. Typically, you'll mix one part starch with two parts water in a spray bottle. Shake the bottle well to ensure the starch is evenly mixed with the water.
3. **Test on a Small Area:** Before applying starch to the entire hat, test it on a small, inconspicuous area to ensure it doesn't cause any discoloration or damage. Wait for the test area to dry completely before proceeding.
4. **Prepare Hat:** Place hat on a clean, flat surface. Ensure hat is clean and free from any dust or debris.
5. **Apply Starch:** Hold the spray bottle about 6-8 inches away from the hat and spray a light, even layer of starch over the entire surface of hat. Avoid saturating the hat with starch, as this can cause it to become stiff or discolored.
6. **Shape Hat:** Use Hat Shaper to shape hat while it's still damp from the starch.



MADE IN THE USA

Assembly Instructions:

1. Plug the USB cable into the back of the control panel.
2. Plug the other end of the USB cable into the USB Adaptor Block
3. Plug the USB Adaptor Block into an electrical outlet.
4. Snap in contoured Hat Shaper Crowns into stationary Base.
5. Slide in the Brim Air Deflector.




Instructions for Use

Welcome to using our adjustable Hat Shaper! This tool is designed to help you maintain and shape your hats to your desired style and fit. Please follow these instructions carefully for optimal results.


1. Adjusting the Size:

- Begin by locating the adjustable crown of Hat Shaper. There is an adjustment by size on both sides of the crown.
- If you know your hat size, line up with the indicator marks on either side.
- If you need to adjust further, remove hat before adjusting. Push in the release on the side of the crown and re-adjust. Re-fit the hat after making adjustments.
- Make sure the adjustment mechanism “clicks” into place. Ensure that Hat Shaper maintains its stability and does not wobble or shift.




2. Shaping Hat:

- Place hat you wish to shape on Hat Shaper. Ensure that hat sits evenly and snugly against the outer circumference of Hat Shaper.
- Gently adjust hat around the crowns to conform to the desired shape. You can manipulate the brim, crown, and overall form of hat as needed.
- Take your time to achieve the desired shape, making small adjustments as necessary.
- Once hat is shaped to your satisfaction, you are ready to start drying.



3. Basic Operation:

- On/Off button – controls the fan speed.
- Click through the positions until the desired fan speed is illuminated.
- Timer button – controls drying time.
- Click through the positions until the desired time is illuminated.



4. Drying:

- Allow hat to air dry completely on Hat Shaper before removing it. This ensures that hat retains its shape as it dries.
- More starch requires longer dry times and slower fan speeds. (High fan speed with heavy starch might cause the starch to separate at each hole location, leaving a small dot of no-starch.)
- More dampness requires longer dry times.

5. Removing Hat:

- Once hat is fully shaped and dry, carefully remove it from Hat Shaper. Take care not to distort the shape of hat during removal.
- Note: when using heavy starch it may be helpful to put a paper towel between hat and Hat Shaper to ease in removal once dry.

6. Additional Tips:

- Experiment with different adjustments and shaping techniques to achieve various hat firmness and fits to create perfectly shaped hats tailored to your preferences!

1-Year Warranty

Coverage: This warranty covers any defects in materials or workmanship for a period of one (1) year from the date of purchase. During this time, we will repair or replace, at our discretion, any product that proves to be defective due to improper materials or workmanship.

Exclusions: This warranty does not cover damage caused by misuse, abuse, neglect, accidents, unauthorized modifications, normal wear and tear, or acts of nature. It also does not cover damage resulting from improper installation, maintenance, or storage.

Claim Process: To make a warranty claim, please contact our customer service department with proof of purchase and a detailed description of the issue. We may require the return of the defective product for inspection or ask for additional information to process the claim.

Resolution: If the product is found to be defective and covered under warranty, we will repair or replace it free of charge. If the exact product is not available, we may offer a comparable replacement or issue a refund for the purchase price.

Limitation of Liability: Our liability under this warranty is limited to the repair, replacement, or refund as stated above. We are not liable for any indirect, incidental, or consequential damages arising from the use of our products.

Legal Rights: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or country to country.

Note: This warranty is subject to change without notice. Please refer to our website or contact customer service for the most up-to-date warranty information.

Care and Maintenance

1. Cleaning: Gently wipe Hat Shaper with a soft, dry cloth to remove dust and debris. For stubborn stains, dampen the cloth slightly with mild soap and water, then wipe the surface clean. Avoid using harsh chemicals or abrasive cleaners as they may damage the material.

2. Drying: Allow Hat Shaper to air dry completely after cleaning before storing or using it again. Avoid exposing it to direct sunlight or heat sources, as this may cause deformation or discoloration.

3. Handling: Handle Hat Shaper with care to avoid bending or misshaping it. Avoid excessive force or pressure when shaping hats to prolong the lifespan of Hat Shaper.

4. Storage: Store Hat Shaper in a cool, dry place away from direct sunlight and moisture. Avoid placing heavy objects on top of Hat Shaper, as this may cause it to lose its shape over time.

By following these care and maintenance instructions, you can prolong the life of your Hat Shaper and ensure it remains in optimal condition for shaping your hats effectively.