



USB-C port on back of device

Package accessories




AC Power
Adapter





USB-C
Cable

Hologram Fish Tank Instructions


- 1.) To turn on the device, plug the included USB-C cable into USB-C port on the back of the Hologram Fish Tank.
 - 2.) Next, plug the other end of the USB-C cable into the included AC power adapter, which plugs into a wall socket.
- We recommend turning the Hologram Fish Tank off occasionally to improve its working lifespan.
 - Be careful not to drop this device or get it wet. It is an electronic device and not waterproof.
 - For questions or troubleshooting, contact us at contact@showcaseholograms.com


 showcaseholograms.com

 contact@showcaseholograms.com

 [@showcaseholograms](https://www.instagram.com/showcaseholograms)

 [@showcaseholograms](https://www.youtube.com/showcaseholograms)

 [showcaseholograms](https://www.facebook.com/showcaseholograms)

 [showcasehologr1](https://twitter.com/showcasehologr1)

 [@theshowcaseholograms](https://www.tiktok.com/@theshowcaseholograms)

This device contains FCC IDs 2AC7Z-ESP32WROOM32U and 2A5BF-A8. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. In order to maintain compliance with FCC regulations, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.