

Quick set up guide:


PRED
TECHNOLOGIES™

TOKK™

TOKK™ 2K WiFi Dash Cam T1pro

A. Instructions, prior to car installation.

1. Insert Micro SD card (not included) in slot **A**
2. Plug the USB charging cable (included) into slot **B**



A-Micro SD Slot
B- USB C Cable
C- Up
D- Mode
E- Down
F-On/Off & OK

B. How to operate the Camera (Without App)

1.To Access the Menu:


- Short Press **D** (Once for main settings, or Twice to access secondary settings)
- To scroll up or down use **C** or **E**. To select a setting press **F**. To go back press **D**.
- To exit the Menu long press **D**

2. To start recording

- Short press **F** to start and stop (every time you will power the Dash Cam it will automatically record)

4. To view recordings

- Exit the Recording mode (Press **F** to stop recording), long press **D** to access recordings, to play/pause press **F**, to select what recordings you want to see or delete press **C** or **E**, to delete press **D** and **C** or **E** to delete or protect and **F** to confirm, to go back long press **D**



1 Scan the code to download the "Roadcam" App

C. Refer to page 10 of the full Instruction Manuel to install the Dash Cam in your car .

D. If you want to use our free App (Not necessary to operate the Dash Cam)

1. Download the "Roadcam" App from the App store or Google Play store. Install the App (follow the prompts) or or scan the QR code (1) to download the App.

2. Connect your Dash Cam to the App:

-Turn on Wifi Switch on Dash Cam (to access it double click **D** to get to Wifi Mode, use **C** or **D** to highlight Wifi Mode, use **C** or **D** to select on or off and select **F** to confirm, press **D** to return to Display mode).

5. On your phone, open settings, open Wifi and select T1Pro-xxx (password is 12345678), press join.

6. Open the Roadcam App and select the Add Recorder. Now you can manage your Dash Cam with App if you wish (Manage the settings of your Dash Cam).